

# CHORE-TIME<sup>®</sup>

## *Poultry Production Systems*

A200-1GLP, A200-1GN, A200-1O

110V and 220V

INCINERATOR

Installation and Operators Manual



Chore-Time Equipment  
P.O. Box 2000  
Milford, IN 46542  
Ph – 574-658-4101  
Fax – 577-730-8825  
[www.choretime.com](http://www.choretime.com)

### **WARRANTY WARNING**

1. Tampering with orifices in the burner will void warranty.
2. Failure to cure refractory before using will void warranty.

39800 CTB 2.6.2014.doc

Manufactured by Firelake MFG., LLC


Installation and Operators Manual

Installation and Operators Manual

# CONTENTS

## TOPIC

LIMITED WARRANTY.....	
WARRANTY WARNING.....	
A200-1 INCINERATOR SPECIFICATIONS.....	
A200-1 PACKING LIST.....	
SITE INFORMATION	
PLACEMENT AND CONSTRUCTION RECOMMENDATIONS.....	
ELECTRICAL SERVICE.....	
FUEL SUPPLY.....	
CONBUSTIBLE ROOF CONSTRUCTION.....	
ASSEMBLY INSTRUCTIONS.....	
BURNER SETTINGS & AIR ADJUSTMENTS.....	
GAS PRESSURE ADJUSTMENTS.....	
OPERATING INSTRUCTIONS.....	
REFRACTORY CURING PROCEDURE.....	
TROUBLE SHOOTING.....	
A200-1 PARTS LIST.....	
MIDCO BURNER (J83-DS) EXPLODED VIEW.....	
PARTS LIST: MIDCO BURNER (J83-DS).....	
BECKETT BURNER (AF) EXPLODED VIEW.....	
PARTS LIST: BECKETT BURNER (AF).....	





# LIMITED WARRANTY

## WARRANTY

Chore-Time Equipment, a division of CTB, Inc., WARRANTOR, warrants to the original purchaser for a period of one (1) year from date of purchase or delivery to original purchase, products manufactured by it which are installed and operated according to WARRANTS'S instructions that are furnished and/or are available to purchaser upon request, and installed according to other applicable Federal, State, and local codes or regulations and upon substantiation that said products were installed correctly, were not abused, and or defective. The exact nature of said warranty and exclusive remedy for breach of warrantor is as follows:

WARRANTOR will refund or credit to purchaser's account an amount equal to the original purchase price or at WARRANTOR'S option repair or replace at WARRANTOR'S expense products found to be defective in workmanship or material. If a problem occurs which the purchaser believes is covered by this warranty, then purchaser shall contact the seller giving the seller sufficient information to enable a resolution to the problem. If the seller is unable or unwilling to resolve the problem and purchaser is still convinced that it is covered by the warranty the purchaser should contact the manufacturer at the address listed in the following paragraph and provide a description in writing of the problem and the attempts made to resolved it. "Seller" as used herein shall mean the dealer or distributor from whom the product was purchased.

No product or part thereof may be returned pursuant to this warranty without first receiving specific written permission to do so. All request should be addressed to Chore-Time Equipment at P.O. 2000, Milford, IN 46542, requesting specific authority for returning merchandise pursuant to this warranty with reasons for the request.

## LIMITATIONS

Products which are abused or neglected are not covered under this Warranty. WARRANTOR shall not be responsible for the costs of removal or reinstallation of its products and shall not be liable for transportation costs to and from it factory. Further, WARRANTOR shall not be liable for replacement, repair, or refund for component parts not manufactured by it.

Use of parts for modification or repair of the unit or any component not authorized or manufactured by Chore-Time Equipment, specifically for this product shall void this warranty.

IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED TO THE SAME PERIOD OF TIME AS THIS EXPRESS LIMITED ONE (1) YEAR WARRANTY AND ARE SPECIFICALLY DISCLAIMED THEREAFTER.

CHORE-TIME EQUIPMENT, SHALL NOT BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, SPECIAL, OR CONTINGENT DAMAGES OR EXPENSES ARISING DIRECTLY OR INDIRECTLY FROM ANY DEFECT IN THE PRODUCT HEREBY WARRANTED.

THIS WARRANTY SHALL BE **VOID** IF SOLVENTS OR OTHER HIGHLY INFLAMABLE FLUIDS, SUCH AS BUT NOT LIMITED TO, BENZENE, METHYLETHYL, KETONES, TOLUENE, XYLENE, OR NAPHTHA ARE BURNED IN OR MIXED WITH OIL FOR BURNING IN USED OIL-FIRED BURNING HEATERS OR FURNACES.

For those states that do not allow limitations on how long an implied warranty lasts, this limitation may not apply. Similarly, for those states that do not allow the exclusion on limitations of incidental or consequential damages, the above exclusions of indirect, incidental, or consequential damages may not apply.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

Chore-Time Equipment is not responsible for any undertaking, representation, or warranty made by dealer, distributor, or other persons, beyond those expressly set forth in this warranty.

### **WARRANTY WARNING**

- 1. Tampering with orifices in the burner will void warranty.**
- 2. Failure to cure refractory before using will void warranty.**



# A200-1 INCINERATOR SPECIFICATIONS

**Table 1: WASTE CHAMBER**

CHAMBLER CAPACITY:	200 lbs. Type IV waste (poultry)
CHAMBER VOLUME:	6.3 cubic feet
DOOR DIMENSION:	18" x 24"
HEIGHT TO DOOR:	30"
REFRATORY:	3", 2800 <sup>f</sup> , 126 lbs/cubic feet
JACKET MATERIAL:	14 gauge aluminized steel
HEIGHT TO TOP OF CHAMBER:	32"

**Table 2: STACK**

DIMINENSIONS:	(1) 12" Dia., 60" L
JACKET:	SS 304-2B 16 GA
STACK CAP:	SS 304-2B: 18 GA (12" Dia. X 14" H)

**Table 3: BURNER**

MODEL: NAT GAS and LP	One (1) Midco J83-DS Direct Main Flame Spark Ignition Electronic Flame Safety, 100% Shut-offs, 800,000 BTUH (maximum)
MODEL: OIL	One (1) Beckett AF Oil Burner W/ Flame Safety, 325,000 BTUH
OPERATION:	One (1) Timer

**Table 4: GENERAL**

EXTERNAL DIMENSIONS:	26" W x 32" H x 40" L (less stack).
OVERALL DIMENSIONS (APPROX.), INCLUDING COUNTERBALANCE WEIGHTS, BURNER, STACK AND STACK CAP	43" W x 101" H x 64" L
ELECTRICAL SERVICE:	Standard-110 volt, 60hz, 20 amp, Also available -- 220 volts, 50hz, 10 amp
GAS SERVICE:	275,000 BTUH (piping sized accordingly) Natural Gas: 7" W.C. (with burner operating) Liquid Propane: 11" W.C. (with burner operating)
GAS/FUEL CONSUMPTION:	Natural Gas = 275 CFH Liquid Propane = 3.0 GPH Fuel Oil = 2.5 GPH
TOTAL WEIGHT:	900 lbs (approx)
PAD REQUIREMENTS:	12' W x 14' L x 4" D (if sheltered) 6' W x 8' L x 4" D (if not sheltered)
PAINT:	1200 degree primer 1200 degree paint

**Table 5: CHARGING RATE**

PATHOLOGICAL:	Up to 200 lbs. per charge of typical pathological waste with a BTU/lb rating of 1000. Batch loaded allowing complete burn-out 4-5 hours, cool down and ash removal before reloading
BURN RATE:	Approx. 45lb./hr.

Must be installed in accordance with local codes and ordinances, subject to regulatory agencies. Stack test data is available from the distributor for permit application. If on-site testing is required, it is the responsibility of the purchaser and can be arranged through the distributor. Outside installation is recommended with a simple metal roof or three-sided metal shelter, provided a **minimum** of four (4) foot clearance from any combustible material. Inside installations may be have special insurance requirements. Factory must be advised.

# A200-1 PACKING LIST

## Package 1: Primary Chamber

1	Primary Chamber w/ top & door assembly
1	Latch
2	Counter Weight Arms
2	Counter Weights

## Package 2: Bolt Package for Primary Chamber

4	3/8 - 16 x 3/4 bolts
6	3/8 - 16 nuts
2	5/16 - 18 nuts
2	5/16 - 18 x 4 bolts
3	#10 x 1/2 TEK Screw

## Package 3: Stack Components

1	5' Stack section
1	Stack cap

## Package 4: Burner Carton

1	Burner Midco J83-DS or Beckett AF
1	Burner cover
1	3/4" Gas cut off valve (NAT Gas and LP only)
1	Pressure gauge (NAT Gas and LP only)
7	1/4 - 20 X 1/2 bolts (oil burner only)
4	1/4 - 20 nuts (oil burner only)
1	Brass flare ell (oil burner only)
1	Brass flare fitting (oil burner only)
1	Brass flare nut (oil burner only)

# SITE INFORMATION

## PLACEMENT AND CONSTRUCTION RECOMMENDATIONS

- The A200 incinerator is designed for outdoor installation on a concrete slab 6' x 8' x 4" thick. (12' x 14' x 4" if sheltered)
- The A200 may be installed in a three sided shelter, but must comply with local building and fire codes for clearances from combustible walls and materials. A minimum clearance of 4' around the incinerator is recommended for service and maintenance.
- For recommended construction of a metal chimney through a combustible roof, **See Figure 3: "Combustible Roof Construction Diagram" on page 11**

## ELECTRICAL SERVICE (CONNECT ONLY TO VOLTAGE YOUR BURNER IS RATED TO OPERATE OR DAMAGE WILL OCCUR)

### 115 volts, 60hz, 20 amp for NAT Gas, LP, & Fuel Oil

- Electrical service can be supplied by plugging into the cord set.

**NOTE:** Polarity must be maintained or the burners will not operate. If burners "lock out" after approximately 5 seconds and the blower continues to operate, then the polarity is incorrect. It should be corrected at the power source, not in the incinerator control.

### 220 volts, 50hz, 10 amp for NAT Gas & LP

- Electrical service can be supplied through the electrical cord at the burner by adding the type of plug that will fit your application.

### 220 volts, 50hz, 10 amp Fuel Oil only

1. Loosen the (2) screws and swing open the transformer.
2. Make wire connections as follows:

<u>Electrical Service</u>	<u>Connections at Transformer</u>
L1	Black wire with wire nut
L2	White wire with wire nut

3. Close transformer and tighten screws.
4. Connect the electrical cord from the burner to the timer as follows:

<u>Electrical Cord</u>	<u>Timer terminal</u>
Black wire	L1
White wire	T1





# FUEL SUPPLY

## NAT Gas and LP

### PIPING:


1. Install gas train with 3/4" minimum dia. pipe or tubing. Larger pipe may be needed depending on the gas supply and regulator location. The A200-1G requires 275,000 BTUH for operation.
2. Using soap solution, leak test all gas connections.

### REGULATOR:

1. Use a properly sized regulator which maintains reduced pressure under static conditions when no gas is flowing. (Dead end lock up).
2. For best results install regulator as near as possible to the incinerator.
3. Regulate LP gas to 11" W.C., NAT gas to 7" W.C. (while burner is burning).
4. Do not exceed 14" W.C. under static conditions when there is no gas flow.

### PRESSURE GAUGE:

- A gas pressure gauge is supplied with each incinerator and should be located between the regulator and gas shut off valve, as close to the burner as possible. See below.





## FUEL SUPPLY (CONTINUED)


### Fuel Oil

#### OIL TANK:

1. Since tanks vary in size and fixtures, you may need to make adaptations to use the parts supplied.
2. It is important that a filter be provided in the line between that tank and the incinerator.
3. If the flow outlet is on the underside of the tank, extend a threaded nipple about 2" into the tank to avoid problems from condensation in the bottom of the tank.

#### PIPING:

1. A flaring tool will be needed to form the ends of the copper tubing.
2. Assemble 3/8" copper tubing, oil filter, shut-off valve and fittings between the oil tank and the burner.



# COMBUSTIBLE ROOF CONSTRUCTION

## RECOMMENDED CONSTRUCTION FOR METAL CHIMNEY THROUGH COMBUSTIBLE ROOF

1. DIMENSIONS ARE MINIMUM DISTANCES
2. BASED ON NFPA 82
3. CONSULT LOCAL BUILDING CODES
4. STOCK SHOULD EXTEND NOT LESS THAN 10 FT. HIGHER THAN ANY BUILDING WITHIN 25 FT.





Figure 3: Combustible Roof Construction Diagram

# ASSEMBLY INSTRUCTIONS

1. Position the incinerator on the concrete slab as needed for fuel and electrical hook up.
2. Slide the 5' stack over the outlet collar (holes down).
3. Position the stack cap over the top of the stack and secure with (3) #10 X 1/2 sheet metal screws.
4. Bolt the toggle clamp to the primary chamber at the mount bracket using (4) 3/8-16x3/4 flange bolts and (4) 3/8-16 flange nuts.
5. Attached the counter weight arms to the door arms using (4) 3/8-16x3/4 flange bolts and (4) 3/8-16 flange nuts.
6. Bolt the counter weights to the counter weight arms (be sure door is clamped closed) with 5/16-18 x 5 bolts, 5/16 – 18 Nylock nuts and 5/16 X 2 washers.
7. Attach the burner and housing as described below.
  - a. For Nat Gas & LP burners - Attach the burner cover and burner to the primary chamber with (4) 3/8-16 flange nuts.
  - b. For Fuel Oil Burners -
    1. Make sure that the flange on the burner tube is about 3 1/2" from the burner housing.
    2. Attach the burner cover to the bracket on the burner with (4) 1/4 - 20 X 1/2 bolts and nuts.
    3. Attach the burner to the primary chamber with (4) 3/8-16 flange nuts.

NOTE: FOR BEST BURN  
MAINTAIN 3.50" BETWEEN  
BURNER HOUSING AND FLANGE





# BURNER SETTINGS & AIR ADJUSTMENTS

Table 1: Midco J83-DS Burner

FUEL	AIR SHUTTER	PILOT ORIFICE	ORIFICE	BTUH
LP	Open*	#58	7/32	275,000
NAT.	Open*	#55	5/16	275,000

\*The air shutter is adjusted to the FULL OPEN position from the factory and should never be moved.





Figure 1: Air Shutter (Midco burner)

# BURNER SETTINGS & AIR ADJUSTMENTS (continued)

Table 2: Beckett AF Burner

FUEL	AIR SHUTTER	AIR BAND	NOZZLE	RETENTION HEAD	BTUH
#1 Fuel Oil (Kerosene) or #2 Fuel Oil (Diesel)	1/2 open**	Closed**	2.5 GPH 30 degrees A	F31	325,000

\*\*These openings are approximate. Final adjustments may be necessary at installation.



Air Band indicator  
(Beckett burner)



Air Shutter indicator  
(Beckett burner)



# GAS PRESSURE ADJUSTMENTS (FOR NAT GAS AND LP ONLY)

**\*PROPER GAS PRESSURE IS CRITICAL TO THE OPERATION OF THE INCINERATOR**


Gas pressure must be adjusted when the burner is operating and set as follows:

**Note:** A gas pressure gauge is supplied with each incinerator (NAT Gas and LP only).

**Nat Gas = 7" W.C.**

**L.P. Gas = 11" W.C.**

## DIGITAL TIMER OPERATION



**START BURNER BY SETTING THE TIMER FOR THE DESIRED HOURS OF BURN TIME. PRESS START, THIS WILL START THE BURNER. A FULL LOAD MAY NEED 6 TO 8 HOURS DEPENDING ON MANY FACTORS LIKE FROZEN ANIMALS, OUTSIDE TEMPERATURE, FATTY CONTENT OF LOAD. EXPERIENCE WILL SHOW HOW TO PREDICT THE TIME AND ACHIEVE A BURN AS COMPLETE AS DESIRED.**



***Curing of the refractory is essential prior to burning the first load of waste. See "REFRACTORY CURING PROCEDURE" below.***

## **REFRACTORY CURING PROCEDURE**

Table 1: REFRACTORY CURING PROCEDURE

<b>Procedure</b>	<b>Time</b>
Start burner and burn for	5 minutes
Allow to cool for	15 minutes
burn	5 minutes
cool	15 minutes
burn	15 minutes
cool	15 minutes
burn	15 minutes
cool	15 minutes
burn	30 minutes
cool	15 minutes
burn	30 minutes
cool	15 minutes
burn	1 hour
cool	15 minutes
burn	1 hour
cool	15 minutes
burn	1 hour
cool	15 minutes
burn	2 hour
cool	15 minutes
burn	3 hours
Total Time	12 hours(approximate)

### **Operating instructions**

1. Remove ashes before loading the incinerator.
2. Load incinerator. Keep the waste 6"-8" away from the burner port.
3. Set the timer for interval burn time, press Start. A full load will normally burn out in 6-8 hours.
4. The incinerator will automatically shut off when the burn is completed.
5. For best results, burn daily to a white ash.

There will be hairline cracks and minor scaling of the refractory when curing is complete. This is a normal result of the curing process.

# **TROUBLE SHOOTING**

## **NAT GAS & LP MODELS**

### **No spark at electrodes**

1. Is burner blower operating? Possible defective blower motor.
2. Clean electrodes and pilot igniter assembly. Apply heat if moisture is present.
3. Check electrode position. See drawing in Midco manual for proper adjustment.
4. Defective Honeywell Control Board. Check voltage to 25V terminal on board.
5. Check service breaker, timer, electrical connections, and polarity.

### **Spark but no ignition**

1. Confirm gas pressure. LP gas @ 11" WC or NAT gas @ 7" WC.
2. Clean electrodes and pilot igniter assembly. Apply heat if moisture is present.
3. Check electrode position. See drawing in Midco manual for proper adjustment.
4. Listen to confirm that solenoid gas valve is opening. Possible defective gas valve.
5. Check for dirt in brass pilot orifice tee.

### **If incinerator does not burn properly**

1. Have the ashes been removed at the beginning of the day?
2. Be sure there is no obstruction blocking the burner tube.
3. Is the air shutter in the full open position? See diagram in "BURNER SETTINGS" section of this manual.
4. Check gas pressure while the burner is burning. LP gas @ 11" WC or NAT gas @ 7" WC.

## **FUEL OIL MODELS**

### **No spark at electrodes**

1. Be sure there is no obstruction in the end of the burner tube and there is no soot build-up on the retention head, electrodes or nozzle.
2. Check all electrical connections.
3. Transformer may be burned out. Listen or look to see if there is an arc across the electrodes. Replace transformer if no spark is present.
4. Check for damage to electrodes.
5. Improper firing head adjustment. See Beckett burner installation manual.

### **No oil spray through nozzle**

1. Defective motor. Check to see if blower wheel is turning. If not, check electrical connections and voltage to motor.
2. Air in fuel line. Check all fittings between burners and at fuel tank for tightness. Air may be bled from the fuel line at the fuel pump.
3. Dirt or water in oil tank.
4. Check the plastic coupling between motor and pump for tight fit.
5. Check for clogged filter at tank or on nozzle.
6. Be sure there are no kinks in the oil line.
7. Check the tubing between the pump and nozzle for blockage.
8. Defective pump.

### **If incinerator does not burn properly**


1. Have the ashes been removed at the beginning of the day?
2. Be sure there is no obstruction blocking the burner tube.
3. Are the air bands adjusted correctly? (See "BURNER SETTINGS" section in this manual).
4. Is No. 1 Fuel Oil (Kerosene) or No. 2 Fuel Oil (Diesel) being used as fuel?

# A200

– Single Burner –


BURNERS	
31524	BURNER ASM: A200-1G Complete
31526	BURNER ASM: A200-1GN Not Complete
31530	BURNER ASM: A200-1O Oil Complete
25855	BURNER ASM: A200-1GN Not 220/50
25853	BURNER ASM: A200-1G LP 220v/50/60
23038	BURNER ASM: A200 Oil 220v/50/60
100725	HOUSING: Burner, Gas, 30 Deg
20335	HOUSING: Burner, Oil, Small

31514	MAIN CHAMBER: Complete L/burner & stack
MISCELLANEOUS PARTS	
31510	STACK: Ext, 12" X 5' SS
35024	GAUGE: Gas Pressure, 0-35" WC
34034	MASTIC: Pint Can, 2-1/2 lbs. Cement
34038	CEMENT: Refractory, 55 lb bag
102665	MASTIC: Gallon Can, 20 lbs. cement
32301	PAINT: High Temp Metallic Brown Spray
42200190	ARTISAN Timer w/gasket
42200191	ARTISAN Timer w/gasket 220v





## MIDCO BURNER (J83-DS) EXPLODED VIEW



See parts list on following page.

## PARTS LIST: MIDCO BURNER (J83-DS)

Key	Part Number	Description
A	33116	Manifold
B	33117	Ignitor Gas Inlet Block, Tube and Ignitor Tip Assembly
C	31603	Flange Gasket
D	33125	Blower Wheel
E	101211	Ignitor Control Piping NATURAL -- #55 Drill (.052)
F	34290	Ignitor Control Piping PROPANE -- #58 Drill (.042)
G	33140	Ground Barrier Kit
H	33113	Main Gas Port and Tube Kit – PROPANE
I	31581	Main Gas Port and Tube Kit – NATURAL
J	33129	Transformer 115/1/50-60 Primary, 24V-30VA
	101420	Or Transformer 220/24V 50/60 Hz, 35VA
K	33109	3/4" NPT Gas Valve -- 24 Volt
L	33121	Electrode (spark or flame) - 2 required
M	33138	Electrode Wires, Boots and Strain Reliefs
N	33131	Ignitor Assembly
O	33126	Motor, 115/1/50-60 Hz
	101426	Or Motor, 220/1/60 Hz
P	33112	Ignitor Regulator 1/8 NPT
Q	33120	Thermal Switch
R	33151	DSI Electronic Control Board
S	33118	Input Adjuster Sealing Gasket
Not Shown	33136	PROPANE Conversion Kit
Not Shown	33135	NATURAL Conversion Kit

This exploded view diagram illustrates the assembly of a mechanical device, likely a pump or motor. The components are labeled as follows:



- AA**: Base plate or housing.
- BB**: Small connector or pin.
- CC**: Main housing or casing.
- DD**: Small rectangular component, possibly a valve or sensor.
- EE**: Small rectangular component, possibly a valve or sensor.
- FF**: Flexible hose or tube.
- GG**: Flange or end cap.
- HH**: Flange or end cap.
- II**: Small cylindrical component.
- JJ**: Small rectangular component, possibly a valve or sensor.
- KK**: Small rectangular component, possibly a valve or sensor.
- LL**: Large circular flange or end cap.
- MM**: Large circular flange or end cap.
- NN**: Small rectangular component, possibly a valve or sensor.
- OO**: Small circular component, possibly a seal or gasket.
- PP**: Small circular component, possibly a seal or gasket.
- QQ**: Small circular component, possibly a seal or gasket.
- RR**: Small rectangular component, possibly a valve or sensor.
- SS**: Small rectangular component, possibly a valve or sensor.
- TT**: Small rectangular component, possibly a valve or sensor.

39800 CTB 2.6.2014.doc



## PARTS LIST: BECKETT BURNER (AF)

Item	Description	Part Number
AA	Air band assembly – 8 slot	32322
BB	Air shutter – 8 slot	52321
CC	Escutcheon plate	32323
DD	Pump A2VA7116 ( <i>Suntec</i> ) 110V 220V	32341 10176130
EE	Pump elbow	57210
FF	Connector tube assembly – 8"	101472
GG	Motor 110V 220V	32302 32303
HH	Blower wheel (use only RWB replacement)	57204
II	Coupling	32340
JJ	Primary Control 110V-GeniSys 7505 220V	101279 101268
KK	Cad cell detector	32345
LL	Flange – universal, adjustable, incl. gasket	32365
MM	Gasket only	32320
NN	Transformer 110V 220V	32310 10173200
OO	Retention head	32335
PP	Electrode kit F head air tubes longer than 9"	101474
QQ	Air Tube	32351
Not Shown	Nozzle: 2.50 X 30A	22134



FIRELAKE MFG. L.L.C.  
DASSEL, MN 55325

DATE 1-21-2014  
KC

SIZE

MATL.

DESCRIPTION  
WIRING DIAGRAM:

PART NO.  
AG ARTISAN



# 4970

## Configurable Countdown Timer

The 4970 is a highly flexible countdown interval timer with digital display of timing controlling a set of high current output contacts. The timing cycle range can be configured for any of the following values: 00:01-99:59 Minutes:Seconds, 00:01-99:59 Hours:Minutes, 0001-9999 Seconds, and 00.01-99.99 Seconds. The two arrow buttons on the front panel are used to set the time, the Up button increases the time and the Down decreases it. The longer a button is held down the faster the rate at which the time value will change, the time value rolls around at both ends of the time range.

The Start/Stop button performs multiple functions. Pressing the Start/Stop button while the timer is idle will energize the output power relay contacts and the controller begins counting down the time on the display, once the display reaches 0 the contacts de-energize and the unit alarms for 5 seconds and then returns to the original cycle time. Pressing the Start/Stop button while the controller is timing will pause the controller at the current time and de-energize the output relay contacts. Pressing the Start/Stop button while in pause mode causes the output relay to energize and the controller continues timing from the point at which it was paused. Should the Start/Stop switch be held down for longer than two seconds while in pause mode the controller will reset and the display will return to the original starting time.

Should power fail during a timing cycle the controller remembers the last time value and will recover upon restoration of power dependant on its configuration. The 4970 always remembers the last interval time programmed and when first powered up resets to that time. The LED above the 4 digit display flashes during the timing cycle to indicate timing and is on continuously when the cycle is ended. The 4970 can be configured with a variety of time range, timing adjustment, alarming, power recovery, and power conservation options, see the second page for information.

### Specifications

**Operating Voltage:** 12VDC  $\pm 10\%$ , 115VAC  $\pm 15\%$ , 230VAC  $\pm 15\%$ , 24VAC  $\pm 10\%$ , 50/60 Hz for AC.

**Current Consumption:** See table for operating current at nominal input voltages; Idle = display on, Timing = display & relay on, Standby = display off (option LP:02 selected)

**Timing Accuracy:**  $\pm 0.5\%$  of set time.

**LED Digital Display:** Four digit red LED, 0.56" characters.

**Timing Cycle Memory:** All data stored in non-volatile memory, 10 yr. min. retention with no power.

**Audible Alarm:** Solid state alarm operating dependant on unit configuration.

**Output Contact Ratings:** See table below for various load types and voltages.

**Agency Listing:** UL File E47858: Appliance Controls - Component ATN22 (US), ATN28 (Can)

**Mounting:** 2.63 sq. cutout accepts timer which is secured with supplied bracket & nut. Mounting nut must be tightened to 3 inch pounds.

**Wiring:** .25" Quick Connect terminals.

**Operating Temperature:** 0°C to 70°C.

**Data Sheet Revision Date:** January 23, 2012

#### Operating Current (mA)

	Idle	Timing	Standby
12V DC	55	135	20
115V AC	22	80	19
230V AC	10	15	8.0
24V AC	105	150	95

### Ordering Information

Part Number	Operating Voltage
4970-1	12V DC
4970-2	115V AC
4970-3	230V AC
4970-4	24V AC

#### Output Contact Ratings

	NO Contacts	NC Contacts
Resistive Inductive	20A @ 125/240VAC, 30VDC 6A @ 277VAC	10A @ 125/240VAC, 30VDC 3A @ 277VAC
Motor	2HP @ 240VAC 1HP @ 125VAC	1HP @ 240VAC 1/2HP @ 125VAC
LRA/FLA	60A LRA @ 240VAC 20A FLA @ 240VAC	33A LRA @ 240VAC 10A FLA @ 240VAC
Ballast	6A @ 125/277VAC	3A @ 125/277VAC


VISIT OUR WEB SITE AT: [www.artisancontrols.com](http://www.artisancontrols.com)

**Notice:** Artisan Controls Corporation assumes no responsibility for customers applications or product design, it is the customers responsibility to analyze their application and test the selected product to determine its suitability for use. The information and data contained herein is the sole and exclusive property of Artisan Controls Corporation. Any duplication, misuse, or conversion of this information without the express written consent of Artisan Controls Corporation is illegal and will result in damages including court costs and attorney fees being assessed against the party misusing this property


**Tel: 973-598-9400 • Fax: 973-598-9410 • Toll Free: 800-457-4950**  
**Artisan Controls Corporation, 111 Canfield Ave. Bldg B13-18, Randolph, New Jersey 07869, USA**



## Mechanical



## Wiring



## Configuration

The 4970 can be configured to any of four time ranges by performing the following. Press and hold the down button (center) and apply the power. The unit will display one of the four ranges per this chart

- 0 = 00.01 - 99.99 seconds
- 1 = 00:01 - 99:59 minutes:seconds
- 2 = 0001 - 9999 seconds
- 3 = 00:01 - 99:59 hours:minutes

To change the timing range use the up and down buttons to change the displayed value to the range desired, then turn the controller off. The next time the controller is turned on it will be operating in the selected time range.

More detailed configurations such as styles of beeping and limiting the time range are available by using the Start/Stop button in a similar manner, please refer to the 4970 Users Manual for details

VISIT OUR WEB SITE AT: [www.artisancontrols.com](http://www.artisancontrols.com)

**Notice:** Artisan Controls Corporation assumes no responsibility for customers applications or product design, it is the customers responsibility to analyze their application and test the selected product to determine its suitability for use. The information and data contained herein is the sole and exclusive property of Artisan Controls Corporation. Any duplication, misuse, or conversion of this information without the express written consent of Artisan Controls Corporation is illegal and will result in damages including court costs and attorney fees being assessed against the party misusing this property

**Tel: 973-598-9400 • Fax: 973-598-9410 • Toll Free: 800-457-4950**  
**Artisan Controls Corporation, 111 Canfield Ave. Bldg B13-18, Randolph, New Jersey 07869, USA**