


# Digital WEIGH-MATIC®

## Installation & Operator's Instruction Manual

### Featuring the Model 200 Digital Indicator



## Chore-Time Warranty

**Chore-Time Equipment** warrants each new product manufactured by it to be free from defects in material or workmanship for one year from the date of initial installation by the original purchaser. If such a defect is found by Chore-Time to exist within the one year period, Chore-Time will, at its option, (a) repair or replace such product free of charge, F.O.B. the factory of manufacture, or (b) refund to the original purchaser the original purchase price, in lieu of such repair or replacement.

### Conditions and limitations:

1. The product must be installed and operated in accordance with instructions published by **Chore-Time** or warranty will be void.
2. Warranty is void if **all components** of a system are not supplied by **Chore-Time**.
3. This product must be purchased from and installed by an authorized Chore-Time dealer or certified representative thereof, or the warranty will be void.
4. Malfunctions or failure resulting from misuse, abuse, negligence, alteration, accident, or lack of proper maintenance shall not be considered defects under this warranty.
5. This warranty applies only to systems for the care of poultry and livestock. Other applications in industry or commerce are not covered by this warranty.

**Chore-Time** shall not be liable for any **Consequential or Special Damage** which any purchaser may suffer or claim to have suffered as a result of any defect in the product. **“Consequential” or “Special Damages”** as used herein include, but are not limited to, lost or damaged products or goods, costs of transportation, lost sales, lost orders, lost income, increased overhead, labor and incidental costs and operational inefficiencies.

THIS WARRANTY CONSTITUTES CHORE-TIME’S ENTIRE AND SOLE WARRANTY AND CHORE-TIME EXPRESSLY DISCLAIMS ANY AND ALL OTHER WARRANTIES, INCLUDING, BUT NOT LIMITED TO, EXPRESS AND IMPLIED WARRANTIES AS TO MERCHANTABILITY, FITNESS FOR PARTICULAR PURPOSE SOLD AND DESCRIPTION OR QUALITY OF THE PRODUCT FURNISHED HEREUNDER.

Any exceptions to this warranty must be authorized in writing by an officer of the company. Chore-Time reserves the right to change models and specifications at any time without notice or obligation to improve previous models.

**CHORE-TIME EQUIPMENT, A Division of CTB, Inc.**  
**P.O. Box 2000**  
**Milford, Indiana 46542-2000 U.S.A.**

# Table of Contents

| <b>Topic</b>                                                             | <b>Page</b>    |
|--------------------------------------------------------------------------|----------------|
| <b>Chore-Time Warranty</b> .....                                         | <b>2</b>       |
| <b>Support Information</b> .....                                         | <b>5</b>       |
| <b>Distributor and Installer Information</b> .....                       | <b>5</b>       |
| <b>Safety Information</b> .....                                          | <b>6</b>       |
| Safety–Alert Symbol. ....                                                | 6              |
| Signal Words. ....                                                       | 6              |
| DANGER: Moving Auger ....                                                | 6              |
| DANGER: Electrical Hazard ....                                           | 6              |
| <b>Glossary of Terms.</b> .....                                          | <b>7 - 8</b>   |
| <b>...about the Chore-Time Digital WEIGH-MATIC Scales...</b> .....       | <b>9</b>       |
| Features and Specifications .....                                        | 9              |
| <b>System Planning</b> .....                                             | <b>9 - 11</b>  |
| <b>Site Planning</b> .....                                               | <b>12</b>      |
| <b>Bin Pad Locations and Dimensions.</b> .....                           | <b>12</b>      |
| 7' Storage Bin & Weigh Bin using (2) Pads. ....                          | 12             |
| 9' Storage Bin & Weigh Bin using (2) pads. ....                          | 13             |
| 7' Storage Bin & Weigh Bin using (1) pad ....                            | 13             |
| 9' Storage Bin & Weigh Bin using (1) pad ....                            | 14             |
| <b>Bin Platform Specifications</b> .....                                 | <b>14 - 21</b> |
| (2) 7 Foot, 4 Legged Bins. ....                                          | 15 - 16        |
| (2) 9 Foot, 6 Legged Bins. ....                                          | 17 - 18        |
| 12 Foot, 8 Legged Bins. ....                                             | 19             |
| (2) 12 Foot, 8 Legged Bins. ....                                         | 20 - 21        |
| <b>Load Cell Mount Height</b> .....                                      | <b>22 - 23</b> |
| <b>Installation of the Scale Components</b> .....                        | <b>24 - 29</b> |
| Step 1: Mount Base Location .....                                        | 24             |
| Step 2: Mount Base Assembly and Installation (for T.C. Load Cells) ..... | 24 - 25        |
| Step 2: Mount Base Assembly and Installation (for C.T. Load Cells) ..... | 25 - 26        |
| Step 3: J-Box Location & Installation .....                              | 27             |
| Step 4: J-Box Wiring .....                                               | 27 - 28        |
| Step 5: Duplex Kit Installation .....                                    | 28 - 29        |

|                                                                                        |                |
|----------------------------------------------------------------------------------------|----------------|
| Step 6: Properly Coiling the Cables .....                                              | 30             |
| Step 7: Grounding the System .....                                                     | 31 - 33        |
| Step 8: Indicator Installation.....                                                    | 33 - 34        |
| <b>Wire the Scale System .....</b>                                                     | <b>34 - 39</b> |
| System Wiring Diagram for Suppling Feed from a Bulk Storage Bin .....                  | 35             |
| System Wiring Diagram for Junction Control w/Fill Option #42551 .....                  | 36             |
| (Chore-Time Control not used)                                                          |                |
| System Wiring Diagram for #42551 Control .....                                         | 37             |
| System Wiring Diagram for Junction Control w/Fill Option #42551 .....                  | 38             |
| (using a 34380 Breeder Control)                                                        |                |
| System Wiring Diagram for Dual Fill Control (controlling Weigh-Bin and Fill System) .. | 39             |
| <b>Computer Port (RS-232) .....</b>                                                    | <b>40</b>      |
| System Specifications: .....                                                           | 40             |
| Port Wire Connections — J904 .....                                                     | 40             |
| <b>Setup &amp; Calibration .....</b>                                                   | <b>41 - 43</b> |
| Preparing for Setup & Calibration .....                                                | 41 - 42        |
| Performing the Setup & Calibration: .....                                              | 42             |
| Setup & Calibration Chart .....                                                        | 43             |
| <b>Operation of the Digital WEIGH-MATIC Scales .....</b>                               | <b>44 - 48</b> |
| Balancing the Scale (Zero/Balancing) .....                                             | 44             |
| Selecting the GROSS mode .....                                                         | 45             |
| Selecting the NET mode .....                                                           | 45             |
| To Enter a Preset .....                                                                | 46             |
| To Clear the Preset or Preset Alarm .....                                              | 47             |
| To Pre-load a Tare Value .....                                                         | 47             |
| Changing the Display Language .....                                                    | 48             |
| <b>Parts Lists for the Digital WEIGH-MATIC Scales.....</b>                             | <b>49 - 58</b> |
| Model 200 Indicator .....                                                              | 49             |
| J-Box & Cable Sets.....                                                                | 50             |
| J-Box Duplex Kit .....                                                                 | 50             |
| Miscellaneous Components and Cable Sets .....                                          | 51             |
| Junction Control with Fill Option (Part No. 42550).....                                | 52             |
| Junction Control with Fill Option (Part No. 42551).....                                | 53             |
| Dual Fill Control (Part No. 35021).....                                                | 54             |
| Load Cells and Mount Kits.....                                                         | 55 - 57        |
| Scale System available(by weight).....                                                 | 57             |
| 6-Legged Bin Adapter Kit .....                                                         | 58             |
| 43287 12 VDC Power Supply .....                                                        | 58             |
| <b>Operational Quick Reference Sheets .....</b>                                        | <b>59 - 60</b> |
| <b>Trouble Shooting the Digital Weigh-Matic Scale System.....</b>                      | <b>61 - 65</b> |
| <b>Replacing a CT Load Cell .....</b>                                                  | <b>65 - 66</b> |


# Support Information

The Chore-Time Digital WEIGH-MATIC Scale System is designed to assist in inventorying and metering of poultry and livestock feed. Using this equipment for any other purpose or in a way not within the operating recommendations specified in this manual will void the warranty and may cause personal injury.

This manual is designed to provide comprehensive planning, installation, operation, and parts listing information. The Table of Contents provides a convenient overview of the information in this manual. The Table of Contents also specifies which pages contain information for the sales personnel, installer, and consumer (end user).

**IMPORTANT: CE stands for certified Europe.** It is a standard which equipment must meet or exceed in order to be sold in Europe. CE provides a benchmark for safety and manufacturing issues. **CE is required only on equipment sold in Europe.**

Chore-Time Equipment recognizes CE Mark and pursues compliance in all applicable products. *Fill in the CE-Mark serial number in the blank space provided for future reference.*



## Distributor and Installer Information

Please fill in the following information about your Product.  
Keep this manual in a clean, dry place for future reference.

**Distributor's Name** \_\_\_\_\_

**Distributor's Address** \_\_\_\_\_

**Distributor's Phone** \_\_\_\_\_ **Date of Purchase** \_\_\_\_\_

**Installer's Name** \_\_\_\_\_

**Installer's Address** \_\_\_\_\_

**Installer's Phone** \_\_\_\_\_ **Date of Installation** \_\_\_\_\_

**System Specifications** \_\_\_\_\_

\_\_\_\_\_

## Safety Information

**Caution, Warning and Danger Decals** have been placed on the equipment to warn of potentially dangerous situations. Care should be taken to keep this information intact and easy to read at all times. Replace missing or damaged safety signs.

Using the equipment for purposes other than specified in this manual may cause personal injury and or damage to the equipment.

### Safety–Alert Symbol

**This is a safety–alert symbol.** When you see this symbol on your equipment, be alert to the potential for personal injury. This equipment is designed to be installed and operated as safely as possible...however, hazards do exist.



### Signal Words

**Signal words** are used in conjunction with the safety–alert symbol to identify the severity of the warning.

**DANGER**..... indicates an imminently hazardous situation which, if not avoided, **WILL** result in death or serious injury.



**DANGER**

**WARNING**..... indicates a potentially hazardous situation which, if not avoided, **COULD** result in death or serious injury.



**WARNING**

**CAUTION**..... indicates a hazardous situation which, if not avoided, **MAY** result in minor or moderate injury.




**CAUTION**

### DANGER: Moving Auger

This decal is placed on the Panel Weldment.

Severe personal injury will result, if the electrical power is not disconnected, prior to servicing the equipment.



### DANGER: Electrical Hazard


Disconnect electrical power before inspecting or servicing equipment unless maintenance instructions specifically state otherwise.

Ground all electrical equipment for safety.


All electrical wiring must be done by a qualified electrician in accordance with local and national electric codes.

Ground all non-current carrying metal parts to guard against electrical shock.

With the exception of motor overload protection, electrical disconnects and over current protection are not supplied with the equipment.



# Glossary of Terms




**Mount Base** The Mount Base is the heavy, steel frame that the bin leg sets on. The Load Cell is secured within the Mount Base. (T.C. type shown)


**Load Cell** The Load Cells are the sensing devices of the scale. They mount inside the Base and are secured in place by (2) pins. (T.C. type shown)

**Top Mount** The Top Mount is the flat steel plate that connects the bin leg to the Mount Base.


**Digital Indicator** . . . The Digital Indicator, mounted inside the house, is used to control the scales. It has an electronic, visual readout showing weights and help messages. The Model 200 is equipped with a key pad and other features that allow it to be used to both inventory and meter specific amounts of feed. The Digital Indicator is equipped with an RS-232 port making it capable of communicating with a computer and/or printer.



**Junction Box** . . . . . The J-Box, mounted on a bin leg or within steel framing, serves as a junction box into which all the Load Cells are wired. The Junction Box is referred to as the J-Box throughout this manual.



**Connection Box** . . . . The Connection Box, mounted near the Digital Indicator, is a water tight enclosure used to connect 12 V power from the Transformer to the Indicator power cord.



**Gross Weight** . . . . . Gross weight refers to the total weight on the scale, including feed bin, ladder, feed, fill system, and steel framing (if required).


**Dead Weight** . . . . . Dead weight refers to the weight of the bin, ladder, fill system, and steel framing. Does not include weight of feed. See page 43 (Balancing the Scale).

**Net Weight** . . . . . Net weight refers to the total weight of the feed. Does not include the weight of the bin, fill system, or steel framing.


## Glossary of Terms - continued

---

**Beam Assembly . . . .** The Beam Assembly is used on 6-legged bins that are not to be mounted on a bin platform. The (2) Beam Assemblies carry the load of (2) legs each, thus requiring (4) Mount Kits instead of 6. The Beam Assemblies may be used on bins that carry a maximum gross weight of 48,000 lbs or 21,773 kg.



**Steel Framing. . . . .** Steel framing is used in applications that require both feed bins be combined. One scale system is installed beneath the steel framing.



**Frame not supplied by Chore-Time**

---

## ...about the Chore-Time Digital WEIGH-MATIC Scales...

All Chore-Time Digital WEIGH-MATIC Scale systems include temperature compensation which is advantageous for continuous inventory applications. The temperature compensation provides an accurate inventory of weight through a broad range of temperature variations. The Chore-Time Digital Scale system models available are based on maximum feed capacity. The gross capacity of the scale system includes the weight of the feed bin and FLEX-AUGER Feed Delivery System.

The Digital Scale indicators feature micro-processor control with non-volatile memory to retain the current inventory if power is interrupted. The indicators have a help feature to provide easy set-up and operation.

The Model 200 Digital Indicator may be used to assist in feed inventorying. Additionally, the Model 200 may be used to meter a specific amount of feed in and/or out of the bin.

It is available with a computer interface port (RS 232). The Scale Junction Control is required as a connection box for the Model 200 Indicator.

### Features and Specifications

- Accurate to 99%.
- Weather-resistant to water, moisture, and dust.
- The reliable 12-volt power supply may be connected to 110 or 220 VAC
- Temperature range -20 to 140 degrees F (-28 to 60 degrees C).
- Easy to read back-light LCD display.
- The scales are an effective management tool.
- Easy to use and set-up (scrolling help messages).
- Temperature compensated load cells
- Easy to install and operate.

## System Planning

Carefully plan the system layout prior to beginning the installation.

Important: The standard scale kit includes 30' (9.1 m) of wire to connect the J-Box (mounted on bin leg/frame) to the Indicator (mounted inside the house). For installations that require the J-Box to Indicator distance to be up to 100' (30 m), an Extension Cable must be ordered separately. If desired, the J-Box may be ordered with a 30' (9.1 m), 50' (15.2 m), 70' (21.3), or 90' (27.4 m) cord.

The bin should be installed so that no components (such as ladders, conveyors, conduit, etc.) come in contact with the ground or other building structures in a way that would cause an inaccurate weight reading.

The diagrams, on pages 10 & 11, show the common system layouts for the Digital WEIGH-MATIC Scale components. Refer to the diagram that best fits your particular application. Note: For bins with six legs, use of Beam Assemblies is recommended to a **Maximum** of 24 tons (21772.8 kg).




Figure 1. Digital WEIGH-MATIC System components layout for 4-Legged Bin (side view)




Figure 2. Digital WEIGH-MATIC System components layout for 6-Legged Bin (side view)

| Key | Description   |
|-----|---------------|
| 1   | Indicator Box |
| 2   | J-Box         |
| 3   | Mount Kit     |




Figure 3. Digital WEIGH-MATIC System components layout for (2) Bins and Bin Platform with (4) Load Cells (side view)

| Key | Description   |
|-----|---------------|
| 1   | Indicator Box |
| 2   | J-Box         |
| 3   | Bin Platform  |
| 4   | Mount Kit     |
| 5   | Concrete Pad  |




Figure 4. Digital WEIGH-MATIC System components layout for (2) Bins and Bin Platform with (6) Load Cells (side view)

| Key | Description   |
|-----|---------------|
| 1   | Duplex Kit    |
| 2   | J-Box         |
| 3   | Concrete Pad  |
| 4   | Mount Kit     |
| 5   | Bin Platform  |
| 6   | Indicator Box |

## Site Planning

To insure accurate operation, the scales must be installed on a flat, level, well drained surface. Chore-Time recommends setting the scales and bins on a 12" (305 mm) thick concrete pad. Consult your feed bin manual for concrete specifications.

Allow concrete to harden completely before anchor bolt holes are drilled.

Refer to the Flex-Auger Installation Manual and the Feed Bin Assembly Manual to determine bin-to-building placement.

For installations that require a storage bin to fill a Weigh Bin, some dimensional specifications are provided (see Figures 5 - 8). For ease of installation and most trouble-free operation, the Weigh Bin should be located directly in line with the FLEX-AUGER Delivery System. Some installations may require the storage bin to be placed at 90 degrees to the fill system. This type of installation is acceptable.

Typically, the Weigh Bin is set 8 to 10 feet (2.4 to 3 m) from the building. This varies somewhat depending on the desired height of the FLEX-AUGER System inside the building. Two 45 degree PVC elbows and one 10 foot (3 m) PVC tube are required to go between the Weigh Bin and the building. To place the bin nearer to or farther from the building, additional tubes or elbows may be required.

Note: One pad should be used for installations that require a Bin Platform. Refer to the Bin Platform Information and Specifications on pages 15 through 21.

## Bin Pad Locations and Dimensions

### 7' Storage Bin & Weigh Bin using (2) Pads




Figure 5. Bin Pad Layout and Position Diagram (top view)

| Key | Description         |
|-----|---------------------|
| 1   | House               |
| 2   | 7' Dia. Storage Bin |
| 3   | Weigh-Bin           |

# Bin Pad Locations and Dimensions - Continued

## 9' Storage Bin & Weigh Bin using (2) pads




Figure 6. Bin Pad Layout and Position Diagram (top view)

| Key | Description         |
|-----|---------------------|
| 1   | House               |
| 2   | 9' Dia. Storage Bin |
| 3   | Weigh-Bin           |

## 7' Storage Bin & Weigh Bin using (1) pad




Figure 7. Bin Pad Layout and Position Diagram (top view)

| Key | Description         |
|-----|---------------------|
| 1   | House               |
| 2   | 7' Dia. Storage Bin |
| 3   | Weigh-Bin           |

## Bin Pad Locations and Dimensions - Continued

### 9' Storage Bin & Weigh Bin using (1) pad




Figure 8. Bin Pad Layout and Position Diagram (top view)

| Key | Description         |
|-----|---------------------|
| 1   | House               |
| 2   | 9' Dia. Storage Bin |
| 3   | Weigh-Bin           |


## Bin Platform Specifications

Chore-Time does not supply bin platforms. However, the necessary specifications and dimensions are provided on pages 15 through 21 to have the bin platforms built locally.

Construction drawings, along with steel specifications, are provided for various sizes of bins and scale capacities. Refer to the applicable diagram for the system you are installing. Please note that some of the bin platforms specify a pivot bracket to allow each half of the platform move freely. For specifications of bin platforms other than those supplied in this manual, consult your building contractor/engineer.

# TWO SEVEN FOOT FOUR LEGGED BINS

**ALL DIMENSIONS ARE TO CENTER**



## NOTES:

- 1.) 4 TC125 LOAD CELLS
- 2.) NOTCH ENDS OF THE CROSS BEAMS TO NEST INSIDE BEAMS AS SHOWN
- 3.) USE CAUTION TO MAINTAIN FRAME IN FLAT PLANE.
- 4.) ○ BIN LEGS
- 5.) □ LOAD CELL

**ALL DIMENSIONS ARE TO CENTER**


| BIN SIZE     | BEAM SIZE | LOAD CELL PLACEMENT         |
|--------------|-----------|-----------------------------|
| 7 FT. 2 RING | W8X31     | 59" FROM CENTER OF PLATFORM |
| 7 FT. 3 RING | W8X31     | 59" FROM CENTER OF PLATFORM |
| 7 FT. 4 RING | W8X31     | 59" FROM CENTER OF PLATFORM |

3/16" (5MM) FILLET WELD INTERMITTENT.  
1"(2.5CM) WELD,  
1"(2.5CM) SPACING  
BOTH SIDES

# TWO SEVEN FOOT FOUR LEGGED BINS

**ALL DIMENSIONS ARE TO CENTER**

FIELD DRILL  
MOUNTING HOLES




NOTES:

- 1.) 6 TC125 LOAD CELLS
- 2.) NOTCH ENDS OF THE CROSS BEAMS TO NEST INSIDE BEAMS AS SHOWN
- 3.) USE CAUTION TO MAINTAIN FRAME IN FLAT PLANE.
- 4.) ○ BIN LEGS
- 5.) □ LOAD CELL

**ALL DIMENSIONS ARE TO CENTER**

| BIN SIZE     | BEAM SIZE | LOAD CELL PLACEMENT     |
|--------------|-----------|-------------------------|
| 7 FT. 2 RING | W8X31     | 12" AND 81" FROM CENTER |
| 7 FT. 3 RING | W8X31     | 12" AND 81" FROM CENTER |
| 7 FT. 4 RING | W8X31     | 12" AND 81" FROM CENTER |
| 7 FT. 5 RING | W8X31     | 12" AND 81" FROM CENTER |
| 7 FT. 6 RING | W8X31     | 12" AND 81" FROM CENTER |


## HINGE DETAIL



| HINGE SPECIFICATIONS |                   |
|----------------------|-------------------|
| ASTM A36-36<br>PLATE | ASTM A326<br>BOLT |
| (2) 3/16"x6"x7"      | 5/8"              |

SEE NOTE  
(2)


BUTT WELD  
TOP AND BOTTOM



3/16" (5MM) FILLET  
WELD INTERMITTENT.  
1" (2.5CM) WELD,  
1" (2.5CM) SPACING  
BOTH SIDES

# TWO NINE FOOT SIX LEGGED BINS

ALL DIMENSIONS ARE TO CENTER



## NOTES:

- 1.) 4 CT50 LOAD CELL
- 2.) NOTCH ENDS OF THE CROSS BEAMS TO NEST INSIDE BEAMS AS SHOWN
- 3.) USE CAUTION TO MAINTAIN FRAME IN FLAT PLANE.
- 4.) ○ BIN LEGS
- 5.) □ LOAD CELL

ALL DIMENSIONS ARE TO CENTER


| BIN SIZE     | BEAM SIZE | LOAD CELL PLACEMENT         |
|--------------|-----------|-----------------------------|
| 9 FT. 4 RING | W8X24     | 73" FROM CENTER OF PLATFORM |
| 9 FT. 5 RING | W8X28     | 73" FROM CENTER OF PLATFORM |
| 9 FT. 6 RING | W12X30    | 73" FROM CENTER OF PLATFORM |
| 9 FT. 7 RING | W12X30    | 73" FROM CENTER OF PLATFORM |

3/16" (5MM) FILLET WELD INTERMITTENT.  
1" (2.5CM) WELD,  
1" (2.5CM) SPACING  
BOTH SIDES

# TWO NINE FOOT SIX LEGGED BINS

ALL DIMENSIONS ARE TO CENTER


## HINGE DETAIL



| HINGE SPECIFICATIONS |                   |                |
|----------------------|-------------------|----------------|
| SERIES               | ASTM A36-36 PLATE | ASTM A328 BOLT |
| 2                    | (2) 3/16"x6"x7"   | 3/4"           |
| 7                    | (2) 3/16"x6"x7"   | 5/8"           |
| 8                    | (2) 3/16"x6"x7"   | 1 3/8"         |


ALL DIMENSIONS ARE TO CENTER

| BIN SIZE     | BEAM SIZE | LOAD CELL PLACEMENT    |
|--------------|-----------|------------------------|
| 9 FT. 4 RING | W8X24     | 12" CENTER 96" OUTSIDE |
| 9 FT. 5 RING | W8X24     | 12" CENTER 96" OUTSIDE |
| 9 FT. 6 RING | W8X24     | 12" CENTER 96" OUTSIDE |
| 9 FT. 7 RING | W8X24     | 12" CENTER 96" OUTSIDE |



# ONE TWELVE FOOT EIGHT LEGGED BINS

***ALL DIMENSIONS ARE TO CENTER***



NOTES:


- 1.) 4 CT50 LOAD CELL
- 2.) NOTCH ENDS OF THE CROSS BEAMS TO NEST INSIDE BEAMS AS SHOWN
- 3.) USE CAUTION TO MAINTAIN FRAME IN FLAT PLANE.
- 4.) ○ BIN LEGS
- 5.) □ LOAD CELL

***ALL DIMENSIONS ARE TO CENTER***

| BIN SIZE      | BEAM SIZE | LOAD CELL PLACEMENT         |
|---------------|-----------|-----------------------------|
| 12 FT. 2 RING | W6X20     | 60" FROM CENTER OF PLATFORM |
| 12 FT. 3 RING | W10X22    | 60" FROM CENTER OF PLATFORM |
| 12 FT. 4 RING | W10X22    | 60" FROM CENTER OF PLATFORM |
| 12 FT. 5 RING | W10X22    | 60" FROM CENTER OF PLATFORM |
| 12 FT. 6 RING | W10X22    | 60" FROM CENTER OF PLATFORM |
| 12 FT. 7 RING | W10X26    | 60" FROM CENTER OF PLATFORM |

# TWO TWELVE FOOT EIGHT LEGGED BINS

**ALL DIMENSIONS ARE TO CENTER**



## NOTES:

- 1.) 4 CT50 LOAD CELL
- 2.) NOTCH ENDS OF THE CROSS BEAMS TO NEST INSIDE BEAMS AS SHOWN
- 3.) USE CAUTION TO MAINTAIN FRAME IN FLAT PLANE.
- 4.) ○ BIN LEGS
- 5.) □ LOAD CELL


**ALL DIMENSIONS ARE TO CENTER**

| BIN SIZE      | BEAM SIZE | LOAD CELL PLACEMENT         |
|---------------|-----------|-----------------------------|
| 12 FT. 2 RING | W12X26    | 94" FROM CENTER OF PLATFORM |
| 12 FT. 3 RING | W12X30    | 94" FROM CENTER OF PLATFORM |
| 12 FT. 4 RING | W14X34    | 94" FROM CENTER OF PLATFORM |
| 12 FT. 5 RING | W18X35    | 94" FROM CENTER OF PLATFORM |
| 12 FT. 6 RING | W18X35    | 94" FROM CENTER OF PLATFORM |

3/16" (5MM) FILLET WELD INTERMITTENT.  
1"(2.5CM) WELD,  
1"(2.5CM) SPACING  
BOTH SIDES

# TWO TWELVE FOOT EIGHT LEGGED BINS

ALL DIMENSIONS ARE TO CENTER



## NOTES:

- 1.) 6 LOAD CELL
- 2.) NOTCH ENDS OF THE CROSS BEAMS TO NEST INSIDE BEAMS AS SHOWN
- 3.) USE CAUTION TO MAINTAIN FRAME IN FLAT PLANE.
- 4.) ○ BIN LEGS
- 5.) □ LOAD CELL


ALL DIMENSIONS ARE TO CENTER

| BIN SIZE      | BEAM SIZE | LOAD CELL PLACEMENT      |
|---------------|-----------|--------------------------|
| 12 FT. 2 RING | W10X22    | 12" AND 123" FROM CENTER |
| 12 FT. 3 RING | W10X22    | 12" AND 123" FROM CENTER |
| 12 FT. 4 RING | W10X22    | 12" AND 123" FROM CENTER |
| 12 FT. 5 RING | W10X26    | 12" AND 123" FROM CENTER |
| 12 FT. 6 RING | W10X26    | 12" AND 123" FROM CENTER |
| 12 FT. 7 RING | W10X26    | 12" AND 123" FROM CENTER |

3/16" (5MM) FILLET WELD INTERMITTENT.  
1"(2.5CM) WELD,  
1"(2.5CM) SPACING  
BOTH SIDES


# Load Cell Mount Height

## T.C 15 Mount




| Key | Description      |
|-----|------------------|
| 1   | 5.00" (12.7 cm)  |
| 2   | 4.00" (10.16 cm) |

## T.C. 125 and T.C. 35 Mount




| Key | Description       |
|-----|-------------------|
| 1   | 5.00" (12.7 cm)   |
| 2   | 4.00" (10.16 cm)  |
| 3   | 17.88" (45.42 cm) |

**T.C. 180 Mount**



| Key | Description       |
|-----|-------------------|
| 1   | 9.00" (22.86 cm)  |
| 2   | 8.00" (20.32 cm)  |
| 3   | 15.88" (40.34 cm) |

**C.T 30 Mount**



| Key | Description                |
|-----|----------------------------|
| 1   | 5.80" (14.73 cm)           |
| 2   | 5.00" (12.70 cm)           |
| 3   | .50" (1.27 cm) Mount Plate |

# Installation of the Scale Components

## Step 1: Mount Base Location

Refer to the feed bin assembly instructions to determine the exact dimension between the bin legs.

Lay the Mount Bases in their final locations so that a Top Plate is directly under each feed bin leg. See Figure 9.

Secure the Mount Base to the concrete with the concrete anchors supplied. The T.C. 15 uses 7/16" concrete anchors. All others use the 1/2" concrete anchors.

Secure a Top Mount to each bin leg, using 1/2" hardware supplied.

If the bin legs must be welded to the Top Plate, be careful not to damage the Load Cells (or other components) during welding. Later in the installation, it may be necessary to install some shims between the bin and the Top Mount, therefore welding is not recommended.

**IMPORTANT:** If welding is required, clamp welding ground cable to bin leg (not to the Load Cell Mount).




Figure 9. Mount Base Location (top view)

| Key | Description |
|-----|-------------|
| 1   | Feed Bin    |
| 2   | Mount Base  |
| 3   | Bin Leg     |

## Step 2: Mount Base Assembly and Installation (for T.C. Load Cells)

For ease of installation, lubricate the long end of the Load Cell and the Mount Tube with grease.

Install the long end of the Load Cell in the Mount Tube as shown in Figure 10. The Load Cell should be retained in the Mount Tube using a 3/4" pin, supplied.

Route the cable through either of the 1" (25 mm) holes in the side of the Mount Base.

*Note: Refer to the decal on the Load Cell to determine proper orientation of the Load Cell in the Mount Base.*

Set the bin on the Mount Bases and secure the Top Mounts to the Load Cell using

the 5/8" pins supplied.

When the bin is empty, each mount must equally share the load. Use the shims, supplied with the bin, to evenly distribute the weight. The shims should be located between the bin leg and the Top Mount.





Figure 10. T.C. Mount Base Installation

| Key | Description                     |
|-----|---------------------------------|
| 1   | 5/8" x 5" Quick Pin             |
| 2   | 1-7/8" DB or 2-1/8" DB          |
| 3   | Top Mount                       |
| 4   | 3/4" x 6" Quick Pin             |
| 5   | Route Cable Through Either Hole |
| 6   | Mount                           |

**Step 2: Mount Base Assembly and Installation (for C.T. Load Cells)**

1. Clean Mounts and load cells of all dirt and foreign materials.
  2. With steel plate (item 11) on bin pad between load cell mount and bin pad, tighten bolts (items 4 and 13) as required.
  3. Make sure sealing ring (item 6) and pads (item 12) are not damaged. Replace as needed.
  4. Check to see that all load cell cables are tied to frame as they are routed to junction box. Also check for cuts and cracks in the cables.
  5. Check for vertical alignment. All load cells (item 5) should maintain vertical alignment during entire loading and unloading process. If misaligned, realign load cell mounts (item 2) as required.
  6. Important note: Side bar (item 14) is threaded to receive bolts. It is important that bolts (item 8) not be tightened all the way. Leave 1/8" clearance for side bars (items 7 and 14) to move freely. Install lock washer and nut on bolt (item 8).
  7. For proper checking of side loads each mount must be installed rotated relative to the others. i.e.; side bars (items 7 and 14) must point in different directions.
- CAUTION IMPORTANT NOTICE: Do not weld near load cells or cables.

Remove load cells or cables from area to be welded. Always disconnect indicator from junction box when welding on frame or bin. When welding on frame, place ground on frame as close as possible to area to be welded. When welding on bin, place ground on bin, if welding current is allowed to pass through load cells, it will damage them.



**Figure 11. C.T. Mount Base Installation**

| Key | Description             |
|-----|-------------------------|
| 1   | C.T. 30 Load Cell       |
| 2   | C.T. Mount Half         |
| 3   | M16 x mm Hex Nut        |
| 4   | M16 Lock Washer         |
| 5   | Threaded Plate          |
| 6   | Rubber Shim (pkg of 2)  |
| 7   | Pin                     |
| 8   | Cotter Pin              |
| 9   | M16 x 2 mm x 65 mm Bolt |
| 10  | Welded Plate            |
| 11  | Sealing Sponge Ring     |
| 12  | Steel Plate             |

### Step 3: J-Box Location & Installation

The J-Box is water resistant, but not water proof. Mount the J-Box on a bin leg, nearby wall or other structure, using hardware supplied. See Figure 12.

The J-Box must be mounted close enough to the Mount Bases so that each individual cable will reach the J-Box.

Ground the J-Box to a nearby ground rod. Connect the ground cable to the copper grounding lug on the outside of J-Box.

Note: The standard system is shipped with 30' (9.1 m) of cable to connect the J-Box to the Indicator. For distances up to 100' (30 m), extension cables must be purchased separately. **Do not exceed 100' or 30 m between J-Box and Indicator.**

Note: If more than (4) Mount Bases are to be used, a Duplex Kit must be installed. The Duplex Kit must be ordered separately. Refer to the instructions shipped with the Duplex Kit for proper installation and wiring procedure.




Figure 12. Mount Base Installation (side view)

### Step 4: J-Box Wiring

Care should be taken so that all the cables are loosely routed to the J-Box. Chore-Time recommends routing the cables along the bin leg braces. Where possible, tie the cables to the bin braces and/or together using wire ties.

Use caution not to damage the cable on a sharp corner of the bin. **Do not cut the cable. The cable is calibrated for each individual load cell at the factory.**

Wire each of the Load Cell Cables into the J-Box terminal block. See Figure 13. Use the labels on the printed circuit board as a guide.

Later, when the Indicator is installed, connect the J-Box to the Indicator via the cable marked "TO INDICATOR." Refer to the section on installing the Indicator on pages 28 & 29.




Figure 13. J-Box Installation (front view)

| Key | Description  |
|-----|--------------|
| 1   | Load Cell    |
| 2   | To Indicator |

## Step 5: Duplex Kit Installation

Scale systems that use more than (4) Load Cells require the Duplex Kit. See Figure 14.

The Duplex Kit provides a box with (4) additional terminal blocks for the Load Cell wire leads.

For example a scale using (6) Load Cells would have (4) Load Cells wire into box “A” and (2) Load Cells wired into box “B”. The wire from box “B” must be routed to the horizontal terminal block in box “A”. Route the wire from box “A” to the J902 Indicator. See Figure 14 on page 29.

Note: The combined length of cable “A” and cable “B” must not exceed 100’ (30 m). These cables must be continuous cables with no cuts or splices. Coil the cables as specified in Figure 15 on page 30.

During Setup and Calibration the combined lengths of the cables must be considered when determining the proper setting numbers.




Figure 14. Duplex Kit Installation (front view)


| Key | Description                                            |
|-----|--------------------------------------------------------|
| 1   | Box "A"                                                |
| 2   | Box "B"                                                |
| 3   | To Load Cell (note: not all Load Cell Wires are shown) |
| 4   | To Indicator                                           |

## Step 6: Properly Coiling the Cables

The excess J-Box and Load Cell Cables must be non-inductively coiled as shown, below. Note that when coiled in this manner, there will be an equal number of right hand and left hand coils. See Figure 15.

**DO NOT CUT THE CABLES.**

Use wire ties to secure the excess cable coils to the bin structure, as shown.



**Figure 15. Cable Routing and Coiling (front view)**

| Key | Description                                     |
|-----|-------------------------------------------------|
| 1   | Junction Box                                    |
| 2   | Coil the excess cable and wire tie to bin leg   |
| 3   | Carefully route the cable along the bin framing |
| 4   | Allow enough cable for drip loop                |
| 5   | Cable Tie                                       |

## Step 7: Grounding the System

### Ground Rod Specifications:

The ground rod must be 8' or 2.4 meters long (minimum) and must be free of non-conductive coatings, such as paint or enamel. The ground rod must be made from either: 1) 3/4" (19 mm) diameter or larger galvanized pipe, or 2) 1/2" (13 mm) diameter or larger copper-clad or solid copper rod.

### Ground Cable Specifications:

The ground cable must be at least 6 gauge, solid or stranded copper wire. The wire may be insulated, covered or bare, and should be one continuous length with no splices or joints.

The J-Box and feed/storage bin must all be grounded to provide lightning protection.

Proper grounding is absolutely required to insure warranty coverage.

Chore-Time recommendations for the number and locations of ground rods required are shown in Figure 16 - 18.

- Standard 4-legged bin requires (2) ground rods. Two legs should be grounded to each ground rod. See Figure 16.

- Two (4)-legged bins, with separate scales systems, requires (4) ground rods. Two legs should be attached to each ground rod. See Figure 17.

- Single or multiple bins set on scale platform require (2) ground rods. The ground rods should be located at opposite ends of the pad. Only the platform needs to be attached to the ground rod. See Figure 18.

The ground rod must be installed so that 8' (2.4 m) of its length is in contact with the soil.

The ground rod should be driven as near as possible to vertical and flush with the ground.

The ground rod should be embedded below permanent moisture level in the soil. If the ground rod cannot be driven further than 5' (1.5 m), contact Chore-Time for additional grounding instructions.

The ground rod should be installed as close as possible to the equipment to be protected.

Multiple ground rods should be located at least 6' (1.8 m) apart.

The ground wire should be kept as short as possible, preferably under 5' (1.5 m).

Smooth, gradual bends should be used when routing the cable; avoid sharp corners. Make sure the cable is not restricting the accuracy of the bin in any way. Connect the ground wire to the rod, and to the metal structure, with cast bronze or brass clamps.




Figure 16. Ground Rod placement for single bin installations (top view).




Figure 17. Ground Rod placement for multiple bin installations (top view).

| Key | Description                                        |
|-----|----------------------------------------------------|
| 1   | Feed Bin                                           |
| 2   | Ground Rod                                         |
| 3   | Ground Wire: 6 Gauge<br>Maximum Length: 5' (1.2 m) |

**Note: For Both Graphics**




Figure 18. Ground Rod placement for bin platform installations (top view).

| Key | Description                                        |
|-----|----------------------------------------------------|
| 1   | Feed Bin                                           |
| 2   | Ground Rod                                         |
| 3   | Ground Wire: 6 Gauge<br>Maximum Length: 5' (1.2 m) |


**Step 8: Indicator Installation**

Mount the Indicator to the wall using the self-drilling screws supplied. Mounting holes are provided in the box for ease of installation. See Figure 19.

The Indicator should be mounted in a convenient location inside the building. The power cable should be connected directly to a regulated power supply. The scale end of the power cable is attached to the J901 connector located on the bottom panel of the Indicator.

The Power Supply must be plugged in to either a 110V or 220V 50/60 Hz outlet. Make the following cable connections (see Figure 20);

1. Connect the RED wire from the power cable to +12 VDC.
2. Connect the BLACK wire to -12 VDC.



**Figure 19. Indicator Installation (front view).**

| Key | Description                                                       |
|-----|-------------------------------------------------------------------|
| 1   | Indicator                                                         |
| 2   | Power Supply                                                      |
| 3   | Connection Box                                                    |
| 4   | Power Cord: Do Not Cut Power Cord. Coil excess cable and wire tie |
| 5   | To J-Box                                                          |

**DO NOT CUT THE POWER CORD.  
DO NOT CUT THE J-BOX CORD.**

## Wire the Scale System


**CAUTION:** Wiring should be done only by a qualified electrician.

Refer to the appropriate diagram on pages 35-39 or according to the diagrams in the 34380 Breeder Control Manual (MF1061), included with the Breeder Control Panel.




# System Wiring Diagram for Junction Control w/Fill Option #42551


**Chore-Time Control not used!**




System Wiring Diagram for #42551 Control



JUNCTION CONTROL W/FILL OPTION  
PART NUMBER: 42551



System Wiring Diagram for Dual Fill Control (controlling Weigh-Bin and Fill System)



## Computer Port (RS-232)

### System Specifications:

- The Digital WEIGH-MATIC is capable of communicating with a computer or printer using the RS-232 port provided. The signal levels move between +8 and -8 Volts.
- Data is transmitted and received in the ASCII format, which is allowed by most computers and printers.
- Port Configuration: 1200 BAUD, 1 Start Bit, 7 Data Bits, 1 EVEN Parity Bit, 1 Stop Bit. These parameters are not adjustable in the scale. Equipment interfacing to the scale must match this configuration.
- **Refer to your software supplier for additional information on interfacing your Digital WEIGH-MATIC and computer/printer.**

### Port Wire Connections — J904

- All serial communications use the J904 connector on the bottom panel of the Indicator.

|                            |                                              |                |
|----------------------------|----------------------------------------------|----------------|
| To Printer                 | RS-232 out<br>Printer ground                 | pin 2<br>pin 6 |
| From Computer:             | RS-232 in<br>Computer ground                 | pin 3<br>pin 5 |
| To Score Board:            | RS-232 out<br>Score Board ground             | pin 4<br>pin 7 |
| Score Board<br>Score Board | 20 MA Current loop +<br>20 MA Current loop – | pin 1<br>pin 8 |

## Setup & Calibration

The Chore-Time Digital WEIGH-MATIC Scale Indicator must be calibrated in the field for the specific Load Cells that are to be used.

Carefully follow the instructions below. Improper setup & calibration will result in improper and/or inaccurate scale operation.

### Preparing for Setup & Calibration

1. Determine maximum allowable weight of Load Cells you have to install. Refer to the decal on the Load Cells for this information. Also, determine how many of these are to be installed.

For convenience, mark your system on the Setup & Calibration Chart on page 42. Example: If you have (4) 1,500 lbs. Load Cells, mark the chart as shown in Figure 21.

| Load Cells<br>Description | Kit<br>Part No. | J-Box Cable<br>Length | Set Up Numbers<br>(pounds) |
|---------------------------|-----------------|-----------------------|----------------------------|
| T.C. 15<br>4 Points       | 30209           | 30' (9.1 m)           | 144006                     |
|                           |                 | 50' (15.2 m)          | 144006                     |
|                           |                 | 70' (21.3 m)          | 144006                     |
|                           |                 | 90' (27.4 m)          | 144006                     |
| T.C. 35<br>4 Points       | 30211           | 30' (9.1 m)           | 145015                     |
|                           |                 | 50' (15.2 m)          | 145015                     |
|                           |                 | 70' (21.3 m)          | 145015                     |

Figure 21. Setup & Calibration Chart

2. Determine the (total) length of the cables from the J-Box to the Indicator. Thirty feet (9.1 m) of cable is standard. However, Extension Cables are available to allow the J-Box to be located up to 100' (30 m) from the Indicator.

Mark the applicable length of cable on the chart. Example: If you are using the standard J-Box (includes 30' of cable) and a 30' Extension Cable, mark the chart as shown in Figure 22. When necessary, round up to the next longer length.

| Load Cells<br>Description | Kit<br>Part No. | J-Box Cable<br>Length | Set Up Numbers<br>(pounds) |
|---------------------------|-----------------|-----------------------|----------------------------|
| T.C. 15<br>4 Points       | 30209           | 30' (9.1 m)           | 144006                     |
|                           |                 | 50' (15.2 m)          | 144006                     |
|                           |                 | 70' (21.3 m)          | 144006                     |
|                           |                 | 90' (27.4 m)          | 144006                     |
| T.C. 35<br>4 Points       | 30211           | 30' (9.1 m)           | 145015                     |
|                           |                 | 50' (15.2 m)          | 145015                     |
|                           |                 | 70' (21.3 m)          | 145015                     |
|                           |                 | 90' (27.4 m)          | 145015                     |

Figure 22. Setup & Calibration Chart

- Finally, mark the applicable Setup Numbers and Calibration Numbers, as determined by whether the Indicator is to display in pounds or kilograms, as shown in Figure 23.

| Load Cells Description | Kit Part No. | J-Box Cable Length | Set Up Numbers (pounds) | Calibration Numbers (pounds) | Set Up Numbers (kilograms) | Calibration Numbers (kilograms) |
|------------------------|--------------|--------------------|-------------------------|------------------------------|----------------------------|---------------------------------|
| T.C. 15<br>4 Points    | 30209        | 30' (9.1 m)        | 144006                  | 5300                         | 544002                     | 2404                            |
|                        |              | 50' (15.2 m)       | 144006                  | 5314                         | 544002                     | 2410                            |
|                        |              | 70' (21.3 m)       | 144006                  | 5328                         | 544002                     | 2416                            |
|                        |              | 90' (27.4 m)       | 144006                  | 5342                         | 544002                     | 2423                            |
| T.C. 35<br>4 Points    | 30211        | 30' (9.1 m)        | 145015                  | 14358                        | 545016                     | 6512                            |
|                        |              | 50' (15.2 m)       | 145015                  | 14390                        | 545016                     | 6527                            |
|                        |              | 70' (21.3 m)       | 145015                  | 14425                        | 545016                     | 6543                            |
|                        |              | 90' (27.4 m)       | 145015                  | 14465                        | 545016                     | 6561                            |

Figure 23. Setup &amp; Calibration Chart

## Performing the Setup & Calibration:

- Check installation of the Indicator. Make sure Indicator and/or cords are not damaged.
- Connect the Indicator to a 12 volt power supply as specified in the wiring diagrams in this manual.

Do not connect the Load Cells to the Indicator during Setup & Calibration.

The Indicator will automatically be activated when 12V power is supplied to the unit.

- The Indicator will display "HELLO" for a few seconds, then go to a number display.
- Press "ON" to view existing Setup and Calibration numbers.

Note: Indicators are factory setup and calibrated for (4) T.C. 125 Load Cells (48,000 lbs. or 21,773 k) and 30' (9.1 m) of cable. No further setup is required for this configuration. For all other configurations, go to Step 5.


- Press and hold** the "BAL/ZERO" key and the "ON" key until "SETUP" is displayed.
- The first number to display will be the setup number. The flashing digit is ready to be set.
- Refer to the Setup & Calibration numbers previously determined (and marked).  
Use the NET/GROSS key to scroll the number. When the correct number is displayed, press the TARE key to go to the next digit.  
Repeat this procedure to set all the setup numbers.
- Press the "ON" key to move to the calibration numbers.
- Follow the procedure specified in step 7 to set the Calibration numbers.
- Press the "ON" key to exit setup.
- To check the Setup & Calibration numbers, press the "ON" key.
- After the setup review has been completed, press the NET/GROSS key then the BAL/ZERO key to zero out the Indicator. The display should show (0).

## Setup & Calibration Chart

| Load Cells Description   | Kit Part No.     | J-Box Cable Length                                                    | Set Up Numbers (pounds)              | Calibration Numbers (pounds)     | Set Up Numbers (kilograms)           | Calibration Numbers (kilograms)  |
|--------------------------|------------------|-----------------------------------------------------------------------|--------------------------------------|----------------------------------|--------------------------------------|----------------------------------|
| T.C. 15<br>3 Point       |                  | 30' (9.1 m)                                                           | 144006                               | 3964                             | 544002                               | 1798                             |
| T.C. 15<br>4 Points      | 30209            | 30' (9.1 m)<br>50' (15.2 m)<br>70' (21.3 m)<br>90' (27.4 m)           | 144006<br>144006<br>144006<br>144006 | 5300<br>5314<br>5328<br>5342     | 544002<br>544002<br>544002<br>544002 | 2404<br>2410<br>2416<br>2423     |
| T.C. 35<br>4 Points      | 30211            | 30' (9.1 m)<br>50' (15.2 m)<br>70' (21.3 m)<br>90' (27.4 m)           | 145015<br>145015<br>145015<br>145015 | 14358<br>14390<br>14425<br>14465 | 545016<br>545016<br>545016<br>545016 | 6512<br>6527<br>6543<br>6561     |
| T.C. 35<br>6 Point       |                  | Duplex<br>30' (9.1 m)<br>50' (15.2 m)<br>70' (21.3 m)<br>90' (27.4 m) | 145022<br>145022<br>145022<br>145022 | 21715<br>21760<br>21815<br>21875 | 545009<br>545009<br>545009<br>545009 | 9849<br>9870<br>9895<br>9922     |
| T.C. 125<br>4 Point      | 30212 &<br>30213 | 30' (9.1 m)<br>50' (15.2 m)<br>70' (21.3 m)<br>90' (27.4 m)           | 146052<br>146052<br>146052<br>146052 | 32875<br>32960<br>33050<br>33135 | 546023<br>546023<br>546023<br>546023 | 14911<br>14950<br>14991<br>15029 |
| T.C. 125<br>6 Point      |                  | Duplex<br>30' (9.1 m)<br>50' (15.2 m)<br>70' (21.3 m)<br>90' (27.4 m) | 147075<br>147075<br>147075<br>147075 | 49720<br>49850<br>49985<br>50115 | 547034<br>547034<br>547034<br>547034 | 22552<br>22611<br>22672<br>22731 |
| T.C. 125<br>8 Point      |                  | Duplex<br>30' (9.1 m)<br>50' (15.2 m)<br>70' (21.3 m)<br>90' (27.4 m) | 147100<br>147100<br>147100<br>147100 | 66830<br>67000<br>67185<br>67360 | 547045<br>547045<br>547045<br>547045 | 30313<br>30390<br>30474<br>30554 |
| T.C. 180/180A<br>4 Point | 30214            | 30' (9.1 m)<br>50' (15.2 m)<br>70' (21.3 m)<br>90' (27.4 m)           | 147072<br>147072<br>147072<br>147072 | 33040<br>33130<br>33210<br>33300 | 547032<br>547032<br>547032<br>547032 | 14986<br>15027<br>15063<br>15104 |
| T.C. 180/180A<br>6 Point | 30215            | Duplex<br>30' (9.1 m)<br>50' (15.2 m)<br>70' (21.3 m)<br>90' (27.4 m) | 147108<br>147108<br>147108<br>147108 | 50060<br>50195<br>50315<br>50450 | 547048<br>547048<br>547048<br>547048 | 22706<br>22760<br>22822<br>22883 |
| T.C. 180/180A<br>8 Point |                  | Duplex<br>30' (9.1 m)<br>50' (15.2 m)<br>70' (21.3 m)<br>90' (27.4 m) | 148144<br>148144<br>148144<br>148144 | 67290<br>67470<br>67635<br>67820 | 548065<br>548065<br>548065<br>548065 | 30522<br>30603<br>30678<br>30762 |
| T.C. 30K<br>4 Point      | 35020            | 30' (9.1 m)<br>50' (15.2 m)<br>70' (21.3 m)<br>90' (27.4 m)           | 127120<br>127120<br>127120<br>127120 | 32060<br>32150<br>32225<br>32310 | 527054<br>527054<br>527054<br>527054 | 14542<br>14583<br>14617<br>14655 |
| T.C. 125<br>4 Point      |                  | 90' (27.4 m) +<br>30' (9.1 m)<br>J-Box Cable                          | 146052                               | 33235                            |                                      |                                  |
| T.C. 180<br>6 Point      |                  | 90' (27.4 m) +<br>30' (9.1 m)<br>J-Box Cable                          | 147108                               | 50211                            |                                      |                                  |

## Operation of the Digital WEIGH-MATIC Scales

The Digital WEIGH-MATIC Indicator becomes activated when 12 volt power is supplied. A brief message will be displayed ("HELLO"). The scale then selects the GROSS weighing mode. GROSS mode displays the weight change since the unit was last ZERO/BALANCED. Pressing the ON key during normal system operation starts the self-test.



### Balancing the Scale (Zero/Balancing)


1. Press the NET/GROSS key and within three seconds,
2. Press the BAL/ZERO key.

An audible tone will sound.

The ZERO/BALANCE will balance off the dead load (such as the bin, feed, auger, etc.)

"ZERO" is displayed to show completion of the step and the scale is then placed in the GROSS mode.

Pressing only the BAL/ZERO key will cause the following message to appear--"TO ZERO/BALANCE PRESS NET/GROSS - THEN ZERO."




## Selecting the GROSS mode

GROSS mode displays the weight change since the unit was last ZERO/BALANCED.

1. Press the NET/GROSS KEY.

Note: A flashing arrow pointing toward the GROSS text just above the NET/GROSS key indicates that the scale is in the GROSS mode.



## Selecting the NET mode

NET mode displays the weight change after a TARE has been performed. TARE is a temporary zero point.


1. If the scale TARE weight has not been entered, press TARE to display a zero.

or

2. If in the GROSS mode, press NET/GROSS. The NET/GROSS key is an alternating action key. If the scale is in the GROSS mode, pressing the NET/GROSS key will place it in the NET mode. If the scale is in the NET mode, pressing the NET/GROSS key will place it in the GROSS mode.

If the TARE function has not been previously performed, the unit will stay in the GROSS mode and the following message will scroll across the screen--"FOR NET MODE PRESS TARE."

NOTE: A flashing arrow pointing toward the NET text just above the TARE key indicates that the scale is in the NET mode.



## To Enter a Preset

1. Use the numeric keypad to enter the desired preset weight value.
2. Press either NET/GROSS or FILL/FEED to enter a preset value and select the “display mode”.

The FEED annunciator outer triangle will turn ON when the preset amount is entered.

Once the preset has been entered, the display can show the weight data in three (3) different “display modes”.

The three display modes are:

**GROSS MODE:** The gross weight is displayed by pressing the NET/GROSS key. As ingredients are loaded, the weight display will count upward toward the preset value. As ingredients are unloaded the weight display will count down to the preset value.

**FILL/FEED MODE:** Press the FILL/FEED key to display the amount remaining feed to be loaded or unloaded. As ingredients are loaded OR unloaded, the display will count down from the entered preset weight until it reaches zero.


**NET MODE:** The weight added since the preset has been entered is displayed by pressing the NET/GROSS key two times if in the PRESET LOAD/UNLOAD mode, one time if in the PRESET GROSS MODE. As ingredients are loaded, the weight display will count upward, as they are unloaded the weight display will count down.

Switching between these display modes is possible at any time by simply pushing the appropriate keys.

Before the preset weight is reached, the pre-alarm is activated. This causes the preset display annunciator, the front panel alarm light, the output relay, and the alarm horn all to pulse in sequence with the alarm light.

Set the pre-alarm value to “0” to prevent the alarm output from pulsing.


When the preset weight is reached, the front panel alarm light, the output relay, the feed annunciator, and the alarm horn will all be held ON.



## To Clear the Preset or Preset Alarm


1. Press the CLEAR key.

At this time, a new preset can be entered, or by pressing the CLEAR key a second time (with flashing “0” shown on the display) the scale will return to weighing.



## To Pre-load a Tare Value

The Model 200 will also allow the tare weight to be entered via the numeric keypad. This is performed by entering the weight value on the keypad and then by pressing the TARE Key. The pre-load tare feature is useful for weighing containers after they have already been loaded. If the weight of the container is known, this tare weight could be pre-loaded into the scale and the net weight will be displayed. The tare weight may also be sent to the printer



## Changing the Display Language

The Model 200 Digital Weigh-Matic Indicators include a multilingual feature built in. Five languages are available. They include the following; English, Dutch, French, German, and Spanish.

Follow the steps, below, to change the language to be displayed by your Indicator.

1. Press and hold the **NET/GROSS** key, then press the **ON** key.

Display: *{Langag}*

2. Press the **NET/GROSS** key to toggle through the languages available.

English

Italian

French

Portuguese


Spanish

3. Press and hold the **TARE** key, then press the **ON** key.

The display will be in the language selected.


# Parts Lists for the Digital WEIGH-MATIC Scales

## Model 200 Indicator



| Description                                                   | Part No. |
|---------------------------------------------------------------|----------|
| Model 200 Indicator w/Computer Interface                      | 47595    |
| Model 200 Indicator w/Computer Interface and Junction Control | 30228    |
| Not Shown                                                     |          |
| Cable for RS232 Port                                          | 30189    |
| Power Cable                                                   | 30177    |
| 10' Data Cable                                                | 30194    |
| 20 Milliampere Connector                                      | 30187    |

## J-Boxes & Cable Sets



| Description              | Part No. |
|--------------------------|----------|
| J-Box w/30' Cord         | 30201*   |
| J-Box w/50' Cord         | 30202*   |
| J-Box w/70' Cord         | 30203*   |
| J-Box w/90' Cord         | 30204*   |
| J-Box Assembly (no Plug) | 30182    |
| J-Box Assembly           | 30235    |

### Not Shown


|                                       |         |
|---------------------------------------|---------|
| J-Box Extension Plug Kit (Plugs Only) | 30192   |
| J-Box Extension Cable (Cable Only)    | 30190** |

\*Includes Power Cable and Cord (as specified)

\*\*Sold by the foot

Note: J-Box Cables may be ordered separately. See Miscellaneous Components and Cable Sets Parts List on page 50.

## J-Box Duplex Kit



| Description                 | Part No. |
|-----------------------------|----------|
| J-Box Duplex Kit w/30' Cord | 30207    |
| J-Box Duplex Kit w/50' Cord | 36752    |
| J-Box Duplex Kit w/70' Cord | 36753    |
| J-Box Duplex Kit w/90' Cord | 36754    |


## Miscellaneous Components and Cable Sets

| Description                                  | Part No. |
|----------------------------------------------|----------|
| Standard J- Box Circuit Board                | 42742    |
| Duplex J- Box Circuit Board                  | 42741    |
| J-Box Cable (30')                            | 36690    |
| J-Box Cable (50')                            | 36691    |
| J-Box Cable (70')                            | 36692    |
| J-Box Cable (90')                            | 36693    |
| J-Box Extension Kit (Plugs only, no Cable)   | 30192    |
| J-Box Extension Cable (Cable only)           | 30190    |
| J-Box Extension Cable Assembly               | 30188*   |
| Cable for RS232 Port                         | 30189    |
| Power Cable                                  | 30177    |
| 10' Data Cable                               | 30194    |
| Pulsed Data Cable                            | 34453    |
| 20 Milliampere Connector                     | 30187    |
| "Y" Cable (2 female, 1 male ampe Connectors) | 37692**  |

\* Includes (1) male and (1) female Cannon Plug

\*\* Used with livestock Scales only!


## Junction Control with Fill Option (Part No. 42550)



| Item | Description               | Part No. |
|------|---------------------------|----------|
| 1    | Machined Electric Box     | 42532-1  |
| 2    | Terminal Block Bracket    | 42378    |
| 3    | Relay 12 Volt DC          | 42533    |
| 4    | Mount Base 4x6            | 42375    |
| 5    | B Position Terminal Block | 7270     |
| 6    | # 8 Thread Cut Screw      | 34660    |
| 7    | Terminal Block Decal      | 2526-383 |
| 8    | Decal #42550 Control      | 2529-707 |
| 9    | Toggle Switch Spot        | 34579    |

| Item | Description                  | Part No. |
|------|------------------------------|----------|
| 10   | Grounding Plate              | 42373    |
| 11   | 10-32 Nut                    | 6963     |
| 12   | Lock Washer                  | 305      |
| 13   | 10-32 Ground Screw           | 34682    |
| 14   | Cup Washer                   | 5775     |
| 15   | Wire Tie                     | 6635     |
| 16   | Wire Nut                     | 5907-1   |
| 17   | Supplied with Electrical Box |          |
| 18   | Terminal Block Decal         | 2526-384 |


## Junction Control with Fill Option (Part No. 42551)



| Item | Description               | Part No. |
|------|---------------------------|----------|
| 1    | Terminal Block 8 Position | 7270     |
| 2    | Terminal Block Decal      | 2526-383 |
| 3    | Relay, SPDT 240 VAC       | 28904    |
| 4    | Relay, DPDT 12 VDC        | 42533    |
| 5    | Mount Base 4x6            | 42375    |
| 6    | # 8 Thread Cut Screw      | 34660    |
| 7    | #6-32 Screw SFST          | 34660    |
| 8    | Front Cover Decal         | 2529-708 |
| 9    | 4x6 Machined Box          | 42532-2  |
| 10   | Terminal Block Decal      | 2526-382 |
| 11   | #10-32 Ground Screw       | 34662    |

| Item | Description                  | Part No. |
|------|------------------------------|----------|
| 12   | Lock Washer                  | 305      |
| 13   | Cup Washer                   | 5775     |
| 14   | Switch, DPDT on-off-on       | 34578    |
| 15   | Switch, SPDT on-off-on       | 34579    |
| 16   | Grounding Plate 2 switch     | 42374    |
| 17   | 10-32 Nut                    | 6963     |
| 18   | Wire Nut                     | 5907-1   |
| 19   | Cable Clip                   | 565B     |
| 20   | Wire Tie                     | 6635     |
| 21   | Supplied with Electrical Box |          |
| 22   | Terminal Block Decal         | 2526-384 |

## Dual Fill Control (Part No. 35021)




| Item | Description                   | Part No. |
|------|-------------------------------|----------|
| 1    | Fuse Holder                   | 24431    |
| 2    | 3 Amp Fuse                    | 20472    |
| 3    | Control Box Mount Panel       | 34852    |
| 4    | Control Box                   | 30860-4  |
| 5    | Control Box Latch Pivot       | 30863    |
| 6    | Control Box Latch             | 30862    |
| 7    | 35021 Dual Fill Control Decal | 2529-462 |
| 8    | Neoprene Seal                 | 34767    |
| 9    | Clear Lid                     | 30859-1  |
| 10   | DPDT 240 VAC Relay            | 28904    |
| 11   | Back Mount Panel              | 34564    |
| 12   | Terminal Mount Bracket        | 34563    |
| 13   | Terminal Strip                | 34925    |

| Item | Description            | Part No. |
|------|------------------------|----------|
| 14   | Terminal Mount Bracket | 35094    |
| 15   | Terminal Strip         | 34925-6  |
| 16   | Mounting Strap         | 29014-4  |
| 17   | Toggle Switch          | 34579    |
| 18   | Pilot Light            | 29708    |
| 19   | Pilot Light Assembly   | 35461    |
| 20   | Terminal Block         | 7347     |
| 21   | Mount Bracket          | 35022    |
| 22   | Dual Fill Front Panel  | 36144    |
| 23   | Toggle Switch          | 34578    |
| 24   | Toggle Switch          | 34388    |
| 25   | Relay Socket           | 30234    |
| 26   | Relay                  | 30236    |




\*The Mount Kit does not include the Item #3.

## T.C. 180



| Item | Description                                         | Part No.       |
|------|-----------------------------------------------------|----------------|
| 1    | 3/4" x 6" Quick Pin                                 | 42860          |
| 2    | Top Plate                                           | ----           |
| 3    | T.C. 180 Load Cell<br>T.C. 180 Load Cell w/21' cord | 30223<br>30224 |
| 4    | 5/8" x 4.438" Quick Pin                             | 42862          |
| 5*   | Mount Kit for T.C. 180                              | 30218          |
| 6    | Lynch Pin                                           | 42863          |

\*The Mount Kit does not include the Item #3.

**C.T. 30K**

| Item | Description             | Part No. |
|------|-------------------------|----------|
| 1    | C.T. 30 Load Cell       | 35018    |
| 2    | C.T. Mount Half         | 47625    |
| 3    | M16 x mm Hex Nut        | ----     |
| 4    | M16 Lock Washer         | ----     |
| 5    | Threaded Plate          | 47263    |
| 6    | Rubber Shim (pkg of 2)  | 43410    |
| 7    | Pin                     | ----     |
| 8    | Cotter Pin              | ----     |
| 9    | M16 x 2 mm x 65 mm Bolt | ----     |
| 10   | Welded Plate            | 47624    |
| 11   | Sealing Sponge Ring     | 47622    |
| 12   | Steel Plate             | 41478    |

Note: Items 2 - 11 may be ordered as a Mount Kit for C.T. 30 Scale under Part No. 35017.

**Scale Systems available (by weight):**

|                       |              |
|-----------------------|--------------|
| <b>5,000 Lbs.</b>     | <b>30209</b> |
| 12,000 Lbs.           | 30211        |
| 48,000 Lbs. (7' Bins) | 30213        |
| 48,000 Lbs. (9' Bins) | 30212        |
| 60,000 Lbs.           | 30214        |
| 60,000 Lbs.           | 34580        |
| 80,000 Lbs.           | 34575        |
| 90,000 Lbs.           | 30215        |
| 120,000 Lbs.          | 35020        |

Note: Scale Systems include the Junction Box (or Duplex Kit), Load Cells and Mounts. The Digital Indicator must be ordered separately.



# Operational Quick Reference Sheet for the Model 200 Digital WEIGH-MATIC Indicator


## Turning the Control ON & OFF

The Digital Weigh-Matic Indicator becomes activated when 12 volt power is supplied.

A brief message will be displayed ("HELLO"). The scale then selects the GROSS weighing mode.

GROSS mode displays the weight change since the unit was last ZERO/BALANCED.

Pressing the ON key during normal system operation starts the self test.




## Tare Added Containers, etc.

Press TARE key to tare off any added weights, such as containers, carts, etc.




## Selecting the NET or GROSS mode

Press the NET/GROSS key to toggle between NET and GROSS modes. Press the NET/GROSS key twice to get out of FILL/FEED mode.



## Using the HELP Key


Pressing HELP while displaying weight will display information about the last key pressed.



## Entering a Preset Weight


Use the numeric keypad to enter the desired preset weight value.

Press either NET/GROSS or FILL/FEED to enter the preset value and select the "display mode".




## Balancing the Scale

Press the NET/GROSS key and within three seconds, press the BAL/ZERO key.



## Clear the Preset or Preset Alarm


Press the CLEAR key.



## Operational Quick Reference Sheet for the Model 200 Digital WEIGH-MATIC Indicator


### Display Feed Remaining

Press the FILL/FEED key to display the amount of feed to be loaded or unloaded.



### Display Total Feed Loaded

Press the NET/GROSS key to display total amount of feed loaded.



## Changing the Display Language

The Model 200 Digital Weigh-Matic Indicators include a multilingual feature built in.

Five languages are available. They include the following; English, Dutch, French, German, and Spanish.


Follow the steps, below, to change the language to be displayed by your Indicator.

1. Press and hold the **NET/GROSS** key, then press the **ON** key.  
Display: {Langag}
2. Press the **NET/GROSS** key to toggle through the languages available.  
Display: {ENGLISH} = English  
              {NEDERL} = Dutch  
              {FRANCS} = French  
              {DEUTSH} = German  
              {ESPANL} = Spanish
3. When the desired language is displayed, press the **ON** key.
4. Press and hold the **TARE** key, then press the **ON** key to exit the program.  
The display will be in the language selected.

# Trouble Shooting the Digital Weigh-Matic Scale System

ALWAYS DISCONNECT POWER TO THE SYSTEM WHEN SERVICING OR MAINTAINING THE EQUIPMENT. FAILURE TO DISCONNECT POWER MAY CAUSE INJURY OR DEATH.

Service and maintenance work should be done by a qualified technician only.



| Problem or Symptom                                                                                                                                                            | Possible Cause                | Corrective Action                                                                                                                    |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------|--------------------------------------------------------------------------------------------------------------------------------------|
| Indicator flashes “OVR CAP”                                                                                                                                                   | Overloaded Scale              | Reduce amount feed stored in bin.                                                                                                    |
|                                                                                                                                                                               |                               | Replace existing Load Cells with larger capacity Load Cells.                                                                         |
| Indicator flashes “+RANGE”                                                                                                                                                    | Incorrect setup               | See Setup Procedure in this manual.                                                                                                  |
|                                                                                                                                                                               | Bad Load Cell                 | Replace Load Cell.                                                                                                                   |
|                                                                                                                                                                               | Cut or damaged cable          | Replace cable.                                                                                                                       |
|                                                                                                                                                                               | Bad junction or connection    | Check and tighten all connections.                                                                                                   |
|                                                                                                                                                                               | Defective Indicator           | Replace Indicator                                                                                                                    |
| The Indicator continues to flash “+RANGE” with power ON and the Junction Box disconnected.                                                                                    | Defective Indicator           | Replace Indicator.                                                                                                                   |
| The Indicator flashes “+RANGE” then stops flashing and stabilizes at a weight.                                                                                                | Incorrect Junction Box wiring | Wire Junction Box as specified in this manual.                                                                                       |
|                                                                                                                                                                               | Defective Load Cell           | Test Load Cells by connecting the Load Cells one at a time until the defective Load Cell is identified. Replace defective Load Cell. |
| When certain the Indicator is not defective and all connections inside the Junction Box are correct, the Indicator flashes “+RANGE” when all the Load Cells are disconnected. | Defective Junction Box        | Replace the Junction Box.                                                                                                            |

| Problem or Symptom                                                                                                        | Possible Cause                                                                          | Corrective Action                                                                                                                                                                                                                                                                            |
|---------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>The Indicator will not turn "ON"</p> <p>If power checks out and none of these options help, replace the Indicator.</p> | No power or incorrect power to the Indicator.                                           | <p>Connect correct power to the Indicator (14.5 VDC maximum, 10.5 VDC minimum).</p> <p>Verify that power being supplied to the Indicator by removing the Power Connector (in the Indicator) and measure across Pin 1 (pos.) and Pin 2 (neg.). There should be between 10.5 and 14.5 VDC.</p> |
|                                                                                                                           | Loose connection                                                                        | Tighten all electrical supply connections.                                                                                                                                                                                                                                                   |
|                                                                                                                           | Incorrect Wiring                                                                        | Wire the Scale as specified in this manual.                                                                                                                                                                                                                                                  |
|                                                                                                                           | Defective Indicator                                                                     | Replace Indicator.                                                                                                                                                                                                                                                                           |
|                                                                                                                           | Fuse on external alarm wire blown. This will not prevent the Indicator from turning ON. | Replace 10 amp. fuse.                                                                                                                                                                                                                                                                        |
| No power (or improper power) to Indicator.                                                                                | Incorrect house wiring.                                                                 | Use a meter to verify 110/220 VAC is provided to Power Supply.                                                                                                                                                                                                                               |
|                                                                                                                           | Defective Power Supply                                                                  | Replace Power Supply.                                                                                                                                                                                                                                                                        |

### If your Indicator is unstable (slow drift) note the following:

Variations of 30 pounds (13.61 kg) with the 1" (2.5 cm) DB Cells and up to 350 pounds (158.76 kg) with the 2-1/8" (5.4 cm) DB or larger Cells are normal for most scale systems with daily temperature changes. Temperature compensated cells minimize temperature drift, but do not eliminate drift entirely. Balance the Indicator before use to prevent drift from causing inaccurate weight reading (except for feed bins where you want to save inventory data). For feed bins, scales must be empty before balancing. Note: Moisture in the Junction Box can cause unstable or drifting readings. Make sure J-Box is water tight, check strain reliefs and housing gasket.

### Inaccurate readings are most often caused by the following:

1. Indicators with incorrect setup (i.e. an Indicator that was set up for another scale application).
2. Debris under/around mounts or structure.
3. Mounts or platform not shimmed or supported properly. Consequently, there is not an equal load to each of the Load Cells.
4. Defective Load Cells
5. Load Cells installed upside-down (new installations or replacements).
6. Load Cells installed in mounts backwards. System will usually lock at an unknown weight.


To determine if the inaccuracy is caused by the Indicator or some other factor, stand in the middle of the Scale and note your weight on the Indicator. Stand or hang at each load cell and note each reading. If the readings are within 1 display count, the Indicator is causing the problem.

If you find that one or more of the readings are more than 2 display counts different from the others, then assume that one (or more) of the following items may be causing the problem:

1. Indicator has wrong setup and calibration numbers entered.  
 Fix: Compare the system configuration (size, type, and number of load cells) to the setup chart in this manual (page 42).
2. Debris under/around mounts or structure. Readings will be less than actual if debris are lodged under or around mounts and platform.

- Fix: Insure that the mounts and Load Cells are free of ice and other debris. Inspect for gravel or debris that may have fallen through cracks around the deck.
3. Mounts or platform not shimmed or supported properly to provide equal load at each Load Cell.
- Fix: On platform applications, use a large screw driver or pry bar to pry up on the corners of the deck. If one of the corners has noticeable less resistance, the deck may require shimming.
- On feed bin applications, rock the bin back and forth, checking the mounts for any movement or play. Insure that each mount has equal pressure and is secured to the slab.
4. Defective Load Cell
- Fix: If you suspect that you have a defective Load Cell, check it per the instructions later in this manual (page 60).
5. Load Cell upside-down. If a Load Cell is installed upside-down, that Load Cell would read a negative weight.
- Fix: Visually check each Load Cell for proper orientation. There should be a decal located on top of each Load Cell.
- The Load Cells are manufactured such that the cable exits the same side of each Load Cell. Decal are also placed on the same side of each Load Cell.
6. Indicator will not balance (Zero).
- Fix: Observe the display and watch for the “ZERO” indication to appear for two seconds after performing a balance to verify that the Indicator has balanced.
7. Bad Power Supply.
- Fix: The Indicator will not balance if you have a low power supply (less than 10.5 volts loaded). “LO BAT” should be displayed by the Indicator.
- Disconnect the J-Box and check if the Indicator will balance. If the Indicator will not balance, the Indicator is defective.
8. If the Power Supply is confirmed to be O.K., consider the following:
- Testing the Indicator using a simulator (if available).
- Inspect the Junction Box wiring (see the diagrams on pages 27 & 28).
- Remove the Load Cells and test the Junction Box.
- Test Load Cells.

## Load Cell Connections:



| Key | Description                        |
|-----|------------------------------------|
| 1   | Red Wire: +Excitation              |
| 2   | Green Wire: -Signal                |
| 3   | White Wire: +Signal                |
| 4   | Black Wire: -Excitation and Shield |

## Inspect Junction Box Wiring

1. Connect the Junction Box to the Indicator.
2. Open the Junction Box Cover and check wiring for the following:
  - a. Wires connected to the proper connection point by color code.
  - b. Terminal blocks are clamped onto metal lead not insulation.
  - c. Connections are tight.
3. Check for water or condensation in the Junction Box. If moisture is present, dry the entire box and printed circuit board thoroughly with a hair dryer. Note: If properly wired, there are no hazardous voltages are present in the Junction Box.

## Test the Junction Box

Inspect the Junction Box, as specified above, before testing the Junction Box. Test the Indicator and Junction Box using a simulator.

- a. Disconnect all Load Cell wires from Junction Box.
- b. If the failure mode does not change and the Indicator checked out "O.K." earlier, the Junction Box is probably defective.
- c. If the display stops flashing and stabilizes at a weight, the Junction Box is "O.K."

## Test the Load Cells

When you are confident the Junction Box and Indicator are working properly, test the Load Cells.

1. Disconnect all Load Cells from the Junction Box.
2. Disconnect the Junction Box from the Indicator.
3. Balance the Indicator.
4. Reconnect the Junction Box. The Indicator should still read close to zero. It should be a steady reading.
5. Connect one Load Cell at a time to any Junction Box Terminal. Be sure the connections are tight and connected to the proper location by color code.
6. Observe a positive weight change after each Load Cell is connected. Record the reading of each Load Cell.

There is a problem with any Load Cell that cause the following:


- a). Indicator flashes "+RANGE",
- b). Indicators displays a negative weight (check for upside down Load Cell),

c). Indicator is unstable.

7. Stand over (or hang a weight) each Load Cell and observe increase in weight readings on the Indicator.  
Note: The display weight will be heavy.
8. Disconnect all Load Cells and repeat step “5” and “6” for each Load Cell.
9. After all Load Cells are checked, compare readings. If one Load Cell is substantially different than the others, it is probably defective.

Note: Be sure to compare ALL the Load Cells to insure there are not two defective Load Cells.

## Replacing a CT Load Cell



973-79.TIF 10/97

| Key | Description             |
|-----|-------------------------|
| 1   | C.T. 30 Load Cell       |
| 2   | C.T. Mount Half         |
| 3   | M16 x mm Hex Nut        |
| 4   | M16 Lock Washer         |
| 5   | Threaded Plate          |
| 6   | Rubber Shim (pkg of 2)  |
| 7   | Pin                     |
| 8   | Cotter Pin              |
| 9   | M16 x 2 mm x 65 mm Bolt |
| 10  | Welded Plate            |
| 11  | Sealing Sponge Ring     |
| 12  | Steel Plate             |

1. Disconnect load cell from junction box and detach cable from frame.
2. Remove cotter key (item 5) from stabilizer safety pins (item 6) and remove stabilizer pins.
3. Using a hydraulic jack, lift the corner of the bin high enough to remove load cell (item 1).
4. Check sealing ring (item 2) and pads (item 7) to see that they are in good repair. Replace if necessary.
5. Lower corner of bin and reassemble mount.  
Important Note: Side bar (item 8) is threaded to receive bolts (item 4). It is important that bolts (item 4) not be tightened all the way. Leave 1/8" clearance for side bars (items 3 and 8) to move freely.
6. Route cell cable to junction box and connect leads.



**Made to work.  
Built to last.**

**Contact your nearby Chore-Time distributor or representative for additional parts and information.**

**CTB, Inc.  
P.O. Box 2000  
Milford, Indiana 46542-2000 U.S.A.  
Phone: 547-658-4101 • E-Mail: [ctb@ctbinc.com](mailto:ctb@ctbinc.com)**

**Printed in the U.S.A**