



**CHORE-TIME® Incinerator
Recommended Use Based
on Typical Farm Size**



Broilers Breeders Turkeys

<p>Model A200 200 pounds (91 kg) capacity 6.3 cubic foot (0.18 m³) chamber</p>	40,000	30,000	10,000
<p>Model A400 400 pounds (181 kg) capacity 12.6 cubic foot (0.36 m³) chamber</p>	80,000	60,000	20,000
<p>Model A600 600 pounds (272 kg) capacity 18.9 cubic foot (0.54m³) chamber</p>	120,000	90,000	30,000
<p>Model A850 850 pounds (386 kg) capacity 26.5 cubic foot (0.75 m³) chamber</p>	175,000	120,000	42,500

Base the size of your incinerator on the total pounds of loss (expected flock mortality) that will need to be incinerated each day. Plan to operate the incinerator only once per day when the flock is young. Sizing your unit this way builds in expansion capacity as birds grow older and heavier. Two burns per day is considered maximum capacity.