



*Filter Cleaning Instructions for
Flushable Filter Control Panels*

The Filter Control Panel includes a *flushable* filter. Follow the appropriate Filter Cleaning instructions for your system.

Low Pressure Systems: To clean the filter, close the incoming valve on the Control Panel.

Unscrew the Filter Canister and remove the Filter Tube.

Rinse the Filter Tube with clean water to remove debris and/or build-up from the Screen.

Reassemble the Filter Tube and Canister on the Control Panel.

Open the incoming valve.

High Pressure Systems: To clean the filter, close the outgoing valves and open the valve below the filter.

Allow the water to run at full pressure to clean the filter.

When finished, close the valve below the filter and open the appropriate medicator valves or outlet valve.

October 1995

MW1273A



*Filter Cleaning Instructions for
Flushable Filter Control Panels*

The Filter Control Panel includes a *flushable* filter. Follow the appropriate Filter Cleaning instructions for your system.

Low Pressure Systems: To clean the filter, close the incoming valve on the Control Panel.

Unscrew the Filter Canister and remove the Filter Tube.

Rinse the Filter Tube with clean water to remove debris and/or build-up from the Screen.

Reassemble the Filter Tube and Canister on the Control Panel.

Open the incoming valve.

High Pressure Systems: To clean the filter, close the outgoing valves and open the valve below the filter.

Allow the water to run at full pressure to clean the filter.

When finished, close the valve below the filter and open the appropriate medicator valves or outlet valve.

October 1995

MW1273A