

Fill System Switches


Drop Tube Switches

Proximity Drop Tube Switch w/Relay: **34256**

Proximity Drop Tube Switch w/Relay: **39033**

Proximity Drop Tube Switch: **34254**


Item	Description	34256			39033		34254	
		Mfg'd 12/1995 to 8/1996	Mfg'd 8/1996 to 6/2001	Mfg'd 6/2001 to 5/2004	Mfg'd 10/1996 to 7/2001	Mfg'd 7/2001 to 5/2004	Mfg'd 12/1995 to 1/1996	Mfg'd 1/1996 to 5/2004
		Part No	Part No	Part No	Part No	Part No	Part No	Part No
1	Drop Tube Switch	35901	35901	35901	35901	35901	34576	35901
2	Proximity Switch	34255	34255	34255	38816	38816	34255	34255
3	Adjustable Clamp	3527	3527	3527	3527	3527	3527	3527
4	240 VAC Relay	34733	34654	34654	34654	34654	---	---
5	Switch Box Cover	6776	6776	6776	6776	6776	---	---
6	Switch Box	24702	24702	24702	24702	24702	---	---
7	Gasket	6777	6777	6777	6777	6777	---	---
8	Liquid Tight Connector	23779	23779	23779	23779	23779	---	---
9	Cord Assembly	4999-88	4999-88	4999-88	4999-88	4999-88	---	---
10	Box Plate	24321	24321	24321	24321	24321	---	---
11	Relay Mount Plate	---	---	28701	---	28701	---	---
--	Danger Decal	2527-35	2527-35	2527-35	2527-35	2527-35	---	---



MA1275-10 1/96


SENSOR PLUS™ Switch with Heater: 47956

Item	Description	Mfg'd 7/2002 to 4/2004	Mfg'd 4/2004 to 7/2004
		Part No	Part No
1	Sensor Plus Switch W/Heater	46674	48200
2	Product I.D. Decal	2529-788	2529-788
3	Junction Box Cover	6956	6956
4	Junction Box Gasket	6777	6777
5	Deep Junction Box	42610	42610
6	Drop Tube Housing	47954	47954
7	Adjustment Decal	2526-409	2526-409
8	Machined Cover	47955	47955
9	#10-24 Lock Nut	34019	34019
10	Gasket	6968-1	6968-1



SENSOR PLUS™ Switch with Heater: 46316


Item	Description	Mfg'd 1/2001 to 7/2001	Mfg'd 7/2001 to 2/2002	Mfg'd 2/2002 to 8/2002	Mfg'd 8/2002 to 11/2004	Mfg'd 11/2004 to 1/2005	Mfg'd 1/2005 to Present
		Item	Item	Item	Item	Item	Item
1	Sensor Retainer	46314	46314	46314	46314	46314	46728
2	Switch, Sensor Plus w/Heater	46312	46727	46266	46266	48579	48579
3	#6-32 Nut	771	771	771	771	771	771
4	Machined Junction Box	42627-1	42627-1	42627-1	42627-1	42627-1	42627-1
5	Gasket	6777	6777	6777	6777	6777	6777
6	Junction Box Bottom Cover	6956	6956	6956	6956	6956	6956
7	#10 Screw	28075	28075	28075	28075	28075	28075
8	1/2" Water Tight Connector	23779	23779	23779	23779	23779	23779
9	Plastic Conduit Lock Nut	43662	43662	43662	43662	43662	43662
10	Adjustment Decal	2526-409	2526-409	2526-409	2526-409	2526-409	2526-409
11	Machined Junction Box Cover	46313	46313	46313	42611	42611	42611
12	Danger/Product I.D. Decal	2529-771	2529-771	2529-771	2529-771	2529-771	2529-771
13	Drop Tube Housing	46315	46315	46315	46315	46315	46315
14	Cord Assembly	4999-106	4999-106	4999-106	4999-106	4999-106	4999-106



1678-04 10/2008

SENSOR PLUS™ Universal Drop Tube Switch with Heater: 49260


Item	Description	Mfg'd 1/2004 to 9/2004	Mfg'd 9/2004 to 1/2005	Mfg'd 1/2005 to Present
		Part No	Part No	Part No
1	Sensor Retainer	46314	46314	46728
2	Sensor Plus Switch w/Heater	46266	48579	48579
3	#6-32 Nut	771	771	771
4	Machined Junction Box	42627-1	42627-1	42627-1
5	Gasket	6777	6777	6777
6	Junction Box Bottom Cover	6956	6956	6956
7	#10 Screw	28075	28075	28075
8	1/2" Water Tight Connector	42779	42779	42779
9	Plastic Conduit Lock Nut	43662	43662	43662
10	Adjustment Decal	2526-409	2526-409	2526-409
11	Machined Junction Box Cover	42611	42611	42611
12	Product I.D./Danger Decal	2529-824	2529-824	2529-824
13	Frame-Seal Assembly	49263	49263	49263
14	Cord Assembly	4999-106	4999-106	4999-106
15	#6 Screw	35493	35493	35493



1817-3 1/04


SENSOR PLUS™ Switch with Heater & Safety Timer: 46663

Item	Description	Mfg'd 4/2001 to 2/2002	Mfg'd 2/2002 to 7/2002	Mfg'd 7/2002 to 11/2004	Mfg'd 11/2004 to 1/2005	Mfg'd 1/2005 to Present
		Part No	Part No	Part No	Part No	Part No
1	Gasket	---	---	---	---	6968-1
2	Sensor Retainer	46728	46728	48079	48079	46314
3	Machined Drop Tube Housing	46315	46315	46315	46315	46315
4	Adapter Plate	46731	46731	46731	46731	46731
5	Machined 4" x 6" Box	46729	46729	46729	46729	46729
6	#6-32 Nut	771	771	771	771	771
7	Timer Module	46732	46732	46732	46732	46732
8	#8-32 x 3/8" Screw	46092	46092	46092	46092	46092
9	#6-32 x 7/8" Screw	46986	46986	46986	46986	46986
10	#6 Screw	46011	46011	46011	46011	46011
11	#4-40 x 1/4" Screw	46987	46987	46987	46987	46987
12	4" x 6" Box Cover	42851	42851	42851	42851	42851
13	4" x 6" Box Cover	42849	42849	42849	42849	42849
14	4" x 6" Gasket	42854	42854	42854	42854	42854
15	Decal	2527-53	2527-53	2527-53	2527-53	2527-53
16	Product I.D. Decal	2529-772	2529-772	2529-772	2529-772	2529-772
17	Sensor Plus Switch w/Heater	46727	46266	46266	48579	48579
18	Switch Box Rear Panel	46730	46730	46730	46730	46730
19	Terminal Block	34925-3	34925-3	34925-3	34925-3	34925-3
20	Decal	2527-54	2527-54	2527-54	2527-54	2527-54
21	Pilot Light	46047	46047	46047	46047	46047
22	90° Quick Connect	40579	40579	40579	40579	40579
23	Decal	2527-55	2527-55	2527-55	2527-55	2527-55
24	Wire Ties	6635	6635	6635	6635	6635




SENSOR PLUS™ Universal Drop Tube Switch with Heater & Safety Timer: 49264

Item	Description	Mfg'd 1/2004 to 9/2004	Mfg'd 9/2004 to 1/2005	Mfg'd 1/2005 to Present
		Part No	Part No	Part No
1	Gasket	---	---	6968-1
2	Sensor Retainer	48079	48079	48079
3	Frame/Seal Assembly	49263	49263	49263
4	Adapter Plate	46731	46731	46731
5	Machined 4 x 6 Box	46729	46729	46729
6	#6-32 Nut	771	771	771
7	Timer Module	46732	46732	46732
8	#8-32 x .375 SFTP Screw	46092	46092	46092
9	#6-32 x .875 SFTP Screw	46986	46986	46986
10	#6 Screw	46011	46011	46011
11	#4-40 x .25 SFTP Screw	46987	46987	46987
12	4 x 6 Plastic Box Cover	42851	42851	42851
13	Plastic Screw	42849	42849	42849
14	4 x 6 Gasket	42854	42854	42854
15	Decal	2527-53	2527-53	2527-53
16	Decal	2529-825	2529-825	2529-825
17	Sensor Plus Switch W/Heater	46266	48579	48579
18	Switch Box Rear Panel	46730	46730	46730
19	Terminal Block	34925-3	34925-3	34925-3
20	Decal	2527-54	2527-54	2527-54
21	Pilot Light	46047	46047	46047
22	90 Degree Quick Connect	40579	40579	40579
23	Decal	2527-55	2527-55	2527-55
24	Wire Ties	6635	6635	6635



Mechanical Drop Tube Switch: ~~14701-1~~**Mechanical Drop Tube Switch: ~~14701-2~~**


Item	Description	14701-1	14701-2
		Part No	Part No
1	#6-32 x 1-1/4" Screw	2220	2220
2	Shield	24332	24628
3	#6-32 Hex Nut	771	771
4	Switch Tube	24323	24626
5	Switch Assembly	14786-2	14786-2
6	1/2" Liquid Tight Connector	23779	23779
7	Switch Box	24324	24324
8	1/2" Conduit Lock Nut	3357	3357
9	Box Plate	24321	24321
10	Relay	24335	24335
11	#8 x 3/8" Screw	13019	13019
12	Gasket	6777	6777
13	Switch Box Cover	6776	6776
14	Twin Helix Screw	6980	6980
15	#8 x 1" Screw	5998	5998
16	On Delay Timer	24209	24209
17	#10-32 Hex Nut	4297	4297
18	Back Plate	24325	24627



Mechanical Drop Tube Switch: 28354**Mechanical Drop Tube Switch: 28355**

Item	Description	28354		28355			
		Mfg'd 11/1993 thru 5/2000	Mfg'd 5/2000 to 7/2004	Mfg'd 10/1994 thru 8/1996	Mfg'd 8/1996 thru 12/1996	Mfg'd 12/1996 thru 5/2000	Mfg'd 5/2000 to 5/2004
Part No	Part No	Part No	Part No	Part No	Part No	Part No	Part No
1	Switch Insulation	1907-5	1907-5	1907-5	1907-5	1907-5	1907-5
*2	SPDT Switch	7114	46091	7114	7114	7114	46091
3	Switch Bracket	7068	7068	7068	7068	7068	7068
4	Danger Decal	2529-403	2529-403	2529-402	2529-402	2529-402	2529-402
5	Switch Box Cover	6776	6776	6776	6776	6776	6776
6	Cord Assembly	4999-85	4999-85	4999-85	4999-85	4999-85	4999-85
7	Cord Assembly	4999-86	4999-86	4999-86	4999-86	4999-86	4999-86
8	On Delay Timer	24411	24411	29566	29566	24209	24209
9	Danger Decal	2527-35	2527-35	2527-35	2527-35	2527-35	2527-35
10	Switch Box	34012	34012	34012	34012	34012	34012
11	DSPT Relay (240V)	---	---	34733	34654	34654	34654
12	Mounting Plate	24321	24321	24321	24321	24321	24321
13	Liquid Tight Connector	23779	23779	23779	23779	23779	23779
14	Drop Tube Front	30335	30335	30335	30335	30335	30335
15	Drop Tube Back	30354	30354	30354	30354	30354	30354
16	Gasket	6777	6777	6777	6777	6777	6777
17	Switch Paddle	34013	34013	34013	34013	34013	34013
18	Switch Paddle Housing	34014	34014	34014	34014	34014	34014
19	Diaphragm Assembly	7900	7900	7900	7900	7900	7900
20	Deflector Shield	28281	28281	28281	28281	28281	28281
21	Paddle Retainer	25045	25045	25045	25045	25045	25045
22	Pivot Bracket	25048	25048	25048	25048	25048	25048
23	Spring	6972	6972	6972	6972	6972	6972
24	Pin	8757	8757	8757	8757	8757	8757
25	Switch Box	34842	34842	34842	34842	34842	34842
26	Gasket	6968-1	6968-1	6968-1	6968-1	6968-1	6968-1


***Use Kit Part Number: 46678 when replacing the (Part Number 7114) switch that was purchased before May 2000.**



Hopper Level Switches


Hopper Level Switch: 2912

Item	Description	Part No
1	High Differential Shield	24993
2	Paddle Cover	2703
3	Paddle	2709
4	#6-32 Hex Nut	771
5	SPDT Switch	2702
6	Frame Weldment	2711
7	---	---
8	Fabric Retainer	2705
9	Back	2707
10	Mounting Bracket	2703
11	Switch Bracket	24991
12	Mounting Bracket Assembly	2911
13	Cover	711
14	Handy Box	1145
15	#6-32 x 7/8" Screw	1921
16	Grommet	24
17	Flat Washer	2955-19
18	#10-32 Crown Lock Nut	6963
19	Spring	24992




Hopper Level Switch: 14550**Hopper Level Switch (International): 27761**

Item	Description	14550				27761		
		Mfg'd 7/1991 thru 6/1997	Mfg'd 6/1997 thru 7/1998	Mfg'd 7/1998 thru 4/2000	Mfg'd 4/2000 to Present	Mfg'd 1/1995 thru 6/1997	Mfg'd 6/1997 thru 4/2000	Mfg'd 4/2000 to Present
Part No	Part No	Part No	Part No	Part No	Part No	Part No	Part No	Part No
1	Gasket	6777	6777	6777	6777	6777	6777	6777
2	Switch Box Cover	6776	6776	6776	6776	6776	6776	6776
3	Switch Box	24678	24678	24678	24678	7841	7841	7841
4	#10-32 Hex Nut	4297	4297	---	---	---	---	---
5	#10 Lock Washer	305	305	---	---	---	---	---
6	Cup Washer	5775	5775	---	---	---	---	---
7	#10-32 Stud	7007	7007	---	---	---	---	---
8	Paddle Shield	24059	24059	24059	24059	24059	24059	24059
9	Switch Brace Bracket	2703	2703	2703	2703	2703	2703	2703
10	Switch Frame Assembly	14499	14499	14499	14499	14499	14499	14499
11	Paddle	14519	14519	14519	14519	14519	14519	14519
12	Switch Frame Assembly	14498	14498	14498	14498	14498	14498	14498
13	Diaphragm	28157	28157	28157	28157	28157	28157	28157
14	High Differential Shield	7808	7808	7808	7808	7808	7808	7808
15	Switch Bracket	7068	7068	7068	7068	7068	7068	7068
16	Gasket	6968-1	6968-1	6968-1	6968-1	6968-1	6968-1	6968-1
17	Spring	6972	6972	6972	6972	6972	6972	6972
18	#10-32 Lock Nut	6963	6963	6963	6963	6963	6963	6963
19	Pin	6775	8757	8757	8757	6775	8757	8757
20	Switch Insulation	1907-5	1907-5	1907-5	1907-5	1907-5	1907-5	1907-5
21	SPDT Switch	7069	7069	7069	46091	7069	7069	46091
22	Danger Decal	2527-35	2527-35	2527-35	2527-35	2527-35	2527-35	2527-35
--	Mounting Bracket Assembly	2911	2911	2911	2911	2911	2911	2911
--	1/2" Liquid Tight Connector	23779	23779	23779	23779	---	---	---
--	2-Terminal Block	---	---	---	---	34925-2	34925-2	34925-2




Hopper Level Proximity Switch: ~~35790~~

Item	Description	Mfg'd 7/1995 thru 8/1996	Mfg'd 8/1996 thru 1/1999	Mfg'd 1/1999 to 5/2004
		Part No	Part No	Part No
1	Mounting Collar	36395	36395	36395
2	Cap	36467	36467	36467
3	Relay	34733	34654	34654
4	1/2" Liquid Tight Connector	23779	23779	24685
5	Switch Box Cover	6776	6776	6776
6	Switch Box Machined	36437	36334-1	36334-1
7	Mounting Cover	36403	37047	37047
8	Control Mount Bracket	36396	36396	36396
9	Screw	6980	6980	6980
10	Switch Mount Bracket	2911	2911	2911
11	Proximity Switch	34255	34255	34255
12	Gasket	6777	6777	6777



Hopper Level SENSOR PLUS™ Switch: 42613

		Mfg'd 3/1999 thru 2/2002	Mfg'd 2/2002 thru 3/2004	Mfg'd 3/2004 thru 9/2004	Mfg'd 9/2004 thru 1/2005	Mfg'd 1/2005 to Present
Item	Description	Part No	Part No	Part No	Part No	Part No
1	Sensor Retainer	---	46314	46314	46314	46728
2	Sensor Plus Assembly	44920	46165	46266	48579	48579
3	Hopper Switch Support Bracket	42612	42612	42612	42612	42612
4	#4-24 x 3/8" Screw	35493	35493	35493	35493	35493
5	15/32" Plastic Nut	43662	43662	43662	43662	43662
6	Liquid Tight Connector	24685	24685	24685	24685	24685
7	Cord Assembly	4999-101	4999-101	4999-101	4999-101	4999-101
8	#6-32 Nut	771	771	771	771	771
9	Machined Cover	42611	42611	42611	42611	42611
10	Adjuster Decal	2526-407	2526-407	2526-409	2526-409	2526-409
11	Switch Mount Bracket	2911	2911	2911	2911	2911
12	Hopper Level Decal	2529-714	2529-714	2529-714	2529-714	2529-714
13	Mount Cover	6956	6956	6956	6956	6956
14	Machined Box	42627-1	42627-1	42627-1	42627-1	42627-1
15	Gasket	6777	6777	6777	6777	6777





Control Unit Extension Switches


Extension Switch: ~~28895~~

Extension Switch w/Delay and Relay: ~~28980~~

		28895	28980			28895	28980
		Mfg'd 1/1992 to 5/2004	Mfg'd 1/1992 to 5/2004			Mfg'd 1/1992 to 5/2004	Mfg'd 1/1992 to 5/2004
Item	Description	Part No	Part No	Item	Description	Part No	Part No
1	Extension Box	28645	28645	13	Electrical Box Mount Plate	---	28891
2	Danger Decal	2527-9	2527-9	14	Frame Weldment	2711	2711
3	Extension Box	28652	28652	15	Switch Bracket	24991	24991
4	Back	2707	2707	16	Switch Insulation	1907-5	1907-5
5	Mounting Bracket	2703	2703	17	Switch	2702	2702
6	Cover	711	711	18	Compression Spring	24992	24992
7	Handy Box	1145	1145	19	Paddle	2709	2709
8	Gasket	---	6777	20	Delay Relay Decal	---	2529-357
9	Switch Box Cover	---	6776	21	Fabric Retainer	2705	2705
10	Relay	---	24335	22	Paddle Cover	28158	28158
11	Delay	---	29566	23	Box Plate	---	24321
12	Switch Box Machined	---	28934	24	Warning Decal	---	2527-15






MF926-4 12/95



Extension Switch: 47847

Extension Switch w/Delay and Relay: 47846

		47847	47846			47847	47846
		Mfg'd 6/2002 to Present	Mfg'd 6/2002 to Present			Mfg'd 6/2002 to Present	Mfg'd 6/2002 to Present
Item	Description	Part No	Part No	Item	Description	Part No	Part No
1	Extension Box	47848	47848	13	Electrical Box Mount Plate	---	28891
2	Danger Decal	2527-9	2527-9	14	Frame Weldment	2711	2711
3	---	---	---	15	Switch Bracket	24991	24991
4	Back	2707	2707	16	Switch Insulation	1907-5	1907-5
5	Mounting Bracket	2703	2703	17	Switch	2702	2702
6	Cover	711	711	18	Compression Spring	24992	24992
7	Handy Box	1145	1145	19	Paddle	2709	2709
8	Gasket	---	6777	20	Delay Relay Decal	---	2529-357
9	Switch Box Cover	---	6776	21	Fabric Retainer	2705	2705
10	Relay	---	24335	22	Paddle Cover	28158	28158
11	Delay	---	29566	23	Box Plate	---	24321
12	Switch Box Machined	---	28934	24	Warning Decal	---	2527-15




Level Switches

Proximity Level Switch w/Relay (1 second to 10 min. delay): 36105

Proximity Level Switch w/o Relay (1 second to 10 min. delay): 36106

Proximity Level Switch w/Relay (1 second to 60 min. delay): 39030

Item	Description	36105			36106	39030	
		Mfg'd 5/1995 thru 3/1996	Mfg'd 3/1996 thru 6/2004	Mfg'd 6/2004 to Present	Mfg'd 3/1996 to Present	Mfg'd 10/1996 thru 6/2004	Mfg'd 6/2004 to Present
Part No	Part No	Part No	Part No	Part No	Part No	Part No	Part No
1	Proximity Switch Assembly	34857	34857	34857	34255	39032	39032
2	Gasket	6777	6777	6777	---	6777	6777
3	Switch Box Cover	6776	6776	6776	---	6776	6776
4	Twin Helix Screw	6980	6980	28075	---	6980	28075
5	Pin	6775	6775	6775	---	6775	6775
6	Box Plate	24321	24321	24321	---	24321	24321
7	#8-18 x 1/2" Screw	8431	8431	8431	---	8431	8431
8	240V Relay	34733	34654	34654	---	34654	34654
9	#6-20 x 3/8" Screw	8939	8939	6782	---	8939	6782
10	Relay Mount Plate	28701	28701	28701	---	28701	28701
11	#10-32 Hex Nut	4297	4297	4297	---	4297	4297
12	Switch Box	34858	34858	34858	---	34858	34858
13	Level Control Decal	2529-444	2529-444	2529-444	---	2529-625	2529-625
14	Drop	35788	35788	35788	35788	35788	35788
15	Adjustable Clamp	3527	3527	3527	3527	3527	3527




MA1275-16 1/95

Proximity Level Switch w/Relay (1 second to 10 min. Delay): 47831

Proximity Level Switch w/o Relay (1 second to 10 min. Delay): 47832

Proximity Level Switch w/Relay (1 second to 60 min. Delay): 47830

Item	Description	47831	47832	47830
		Mfg'd 4/2002 to Present	Mfg'd 4/2002 to Present	Mfg'd 4/2002 to Present
Part No	Part No	Part No	Part No	Part No
1	Proximity Switch Assembly	34857	34255	39032
2	Gasket	6777	---	6777
3	Switch Box Cover	6776	---	6776
4	Twin Helix Screw	28075	---	28075
5	Pin	6775	---	6775
6	Box Plate	28071	---	28071
7	#8-18 x 1/2" Screw	8431	---	8431
8	240V Relay	34654	---	34654
9	#6-20 x 3/8" Screw	6782	---	6782
10	Relay Mount Plate	24321	---	24321
11	#10-32 Hex Nut	4297	---	4297
12	Switch Box	34858	---	34858
13	Level Control Decal	2529-779	---	2529-778
14	Drop	47829	47829	47829
15	Adjustable Clamp	3527	3527	3527




1908-35 11/2006

Boot Switches

Mechanical Switch and Plate Assembly (Single Boot): 6143

Mechanical Switch and Plate Assembly (Twin Boot): 6411


Item	Description	6143	6411
		Part No	Part No
1	Switch Housing	4586	4586
2	Switch	4604	4604
3	Cover Assembly	4609	4609
4	#10-32 x 1" Screw	4418-1	4418-1
5	#10-32 Hex Nut	4297	4297
6	Spring	4976	4976
7	Spring Pin	4589	4589
8	Cord	4737	4737
9	Water-Tight Connector	4589	4589
10	10-24 Hex Nut	313	313
11	Diaphragm Plate	4948	4948
12	Diaphragm Assembly	4956	4956
13	Back Plate Weldment	7698	7697
14	Plunger	4595	4595
15	Seal	6144	6144
16	Switch Clean-Out Cover	6154	6154
17	5/16" Rubber Washer	13-20155	13-20155
18	5/16" Washer	2230	2230
19	5/16-18 Wing Nut	2146	2146



Proximity Switch w/Cannon Ball Guard (Single Boot): 34780


Proximity Switch w/o Cannon Ball Guard (Twin Boot): 34779

		34780		34779	
		Mfg'd 12/1995 thru 6/2004	Mfg'd 6/2004 to Present	Mfg'd 12/1995 thru 6/2004	Mfg'd 6/2004 to Present
Item	Description	Part No	Part No	Part No	Part No
1	Retainer Bracket	30943	30943	30942	30942
2	Box Plate	24321	24321	24321	24321
3	Window Plate	7842	7842	7842	7842
4	Switch Cover Plate	30941	30941	30941	30941
5	Adjustable Clamp	3527	3527	3527	3527
6	Proximity Plate Weldment	34758	34758	34758	34758
7	Sealing Washer	39-20155	39-20155	39-20155	39-20155
8	5/16-18 Wing Nut	2146	2146	2146	2146
9	230V Relay	34733	34654	34733	34654
10	Switch Box Gasket	6777	6777	6777	6777
11	Switch Box Cover	6776	6776	6776	6776
12	1/2" Liquid Tight Connector	23779	23779	23779	23779
13	Switch Box	24702	24702	24702	24702
14	Proximity Switch	34255	34255	34255	34255




Proximity Switch w/Relay: 37553

Item	Description	Mfg'd 2/1996 thru 8/1996	Mfg'd 8/1996 to Present
		Part No	Part No
1	Proximity Switch	34255	34255
2	Proximity Plate Weldment	34758	34758
3	Adjustable Clamp	3527	3527
4	Plate Window	7842	7842
5	Switch Box Cover	6776	6776
6	Gasket	6777	6777
7	Box Plate	24321	24321
8	Relay	34733	34654
9	Switch Box	24702	24702
10	Relay Mount Plate	28701	28701
11	1/2" Liquid Tight Connector	23779	23779



SENSOR PLUS™ Switch: 46910

Item	Description	Mfg'd 11/2001 thru 7/2002	Mfg'd 7/2002 thru 9/2004	Mfg'd 9/2004 to Present
		Part No	Part No	Part No
1	Terminal Strip	34925-5	34925-5	34925-5
2	#10 Screw	28075	28075	28075
3	Terminal Box Cover	46912	46912	46912
4	Switch Box Gasket	6777	6777	6777
5	Gasket	6968-1	6968-1	6968-1
6	#6-32 Nut	771	771	771
7	Switch Box Mount	46911	46911	46911
8	Sensor Spacer	46546	46546	46546
9	Decal	2526-409	2526-409	2526-409
10	Sensor Retainer	46314	46728	46728
11	#10-32 Lock Nut	6963	6963	6963
12	Switch Box	42610	42610	42610
13	#4-24 Screw	35493	35493	35493
14	Sensor Level Switch	46266	46266	48579
15	Cover	6956	6956	6956



This page left blank.