




## Slack Belt Switch Wire Installation

The Tilt Switches are secured to the Switch Brackets as shipped from the factory. However, the Slack Belt Switch Wires must be installed on the Switch Brackets in the field, as shown in the figure below.

The Switch Wire installation is the same for both the left and right hand switches.

The Switch Brackets are marked "L" (left) or "R" (right). Mount the right hand switch on the right hand side of the collector (as viewed from in front of the collector).



Chore-Time Equipment,  
A division of CTB, Inc.  
P.O. Box 2000  
Milford, Indiana 46542-2000  
Phone: 219-658-4101  
Printed in the U.S.A.




## Slack Belt Switch Wire Installation

The Tilt Switches are secured to the Switch Brackets as shipped from the factory. However, the Slack Belt Switch Wires must be installed on the Switch Brackets in the field, as shown in the figure below.

The Switch Wire installation is the same for both the left and right hand switches.

The Switch Brackets are marked "L" (left) or "R" (right). Mount the right hand switch on the right hand side of the collector (as viewed from in front of the collector).



Chore-Time Equipment,  
A division of CTB, Inc.  
P.O. Box 2000  
Milford, Indiana 46542-2000  
Phone: 219-658-4101  
Printed in the U.S.A.