




Meal Time Control

Part Number 49695

The Meal Time Control was designed to work with the CHORE-TRONICS® controls, or any application where a timed output is available.

The Meal Time Control will start and control the length of operation time, the current monitor will hold the contacts until the last motor has been satisfied.


Field Wiring Diagram



Chore-Time Equipment a Division of CTB Inc.
P.O. Box 2000 • Milford, Indiana 46542-2000 • U.S.A.
Phone (574) 658-4101 • Fax (877) 730-8825

E-Mail: poultry@choretime.com • Internet: <http://www.choretime.com>

Parts List



Item	Part No.	Description
1	42853	Box, Control Bottom
2	49697	4 x 6 Cover Deep (Mach)
3	42849	4 x 6 Lid Screws
4	42854	4 x 6 Gasket
5	24431	Holder, Fuse
6	2529-852	Decal, 34385 Meal-Time Control
7	20472	Fuse, 3 Amp
8	49698	Panel, Back Mount
9	49696	Panel, Grounding
10	34925-6	Strip, Terminal
11	28904	Relay, Omron 240 VAC
12	35460	Monitor, Current
13	29708	Light, Pilot
14	34388	Switch, Toggle
15	34578	Switch, Toggle