




Poultry Trainer

Installation Instruction Manual 120V (29333), and 220V (29325)



The Chore-Time Poultry Trainer is a high voltage low amperage unit designed specifically for use with the electrical anti-roost on feeding and watering systems. The Trainer may be used with up to six feeder or water lines.

The red Indicator light glows if the unit is operating satisfactorily. The light will go out in the event of a short circuit. To trace the short, disconnect the wires from the terminal post. Attach the wires to the terminals one at a time until the light goes out again. This indicates the faulty line. That line may remain disconnected so that the rest of the system can operate. Correct the short as soon as possible.

Caution: Be sure to disconnect the power to the Trainer prior to handling it.

Continuous arcing from the anti-roost cable to ground may damage the Poultry Trainer. Correct this problem immediately by removing whatever is shorting out the cable.

Note: This situation is indicated by the Poultry Trainer light flickering or dim.

When connecting the Poultry Trainer to the anti-roost cables, use wire with insulation rated for 1000 volts (C-T Part No. 3297 or equivalent). Avoid running the wire near grounded metal. A wire with 300 or 600 volt insulation will short out, making the anti-roost ineffective.

Be sure the Feeder or Waterer equipment is well grounded through either the Motor wiring or a separate ground wire from the Trainer so that the anti-roost is effective. If the electrical wiring to the Trainer does not have a separate ground-wire, connect the ground terminal to a good ground source.

Always turn the Trainer off while working in the house. This helps to prevent the birds from becoming wild and flighty.

P.O. Box 2000 • Milford, Indiana 46542-2000 • U.S.A.

Phone (574) 658-4101 • Fax (877) 730-8825

E-Mail: ctb@ctbinc.com • Internet: <http://www.ctbinc.com>

Printed in the U.S.A.



MADE TO WORK.

BUILT TO LAST.®

Revisions to this Manual

Revisions to this Manual

Page No.	Description of Change	ECO
	Added 29325	33332

Contact your nearby Chore-Time distributor or representative for additional parts and information.

Chore-Time Group
A division of CTB, Inc.
PO Box 2000
Milford, Indiana 46542-2000 USA
Phone (574) 658-4101 Fax (877) 730-8825
E-mail: www.choretimepoultry.com
Internet: poultry@choretime.com