

Contents

Topic	Page
Chore-Time Warranty	2
CONDITIONS AND LIMITATIONS	3
Purpose of the Repair Parts Manual	4
Control Units	11
MODEL C™ End Control Unit: 1878-8	11
MODEL C™ End Control Unit, Single Phase: 24396	12
MODEL C™ End Control Unit, Three Phase: 27757	13
MODEL C2® End Control Unit, Single Phase: 28116	14
MODEL C2® End Control Unit, Three Phase: 28270	14
MODEL C2® PLUS Standard End Control Unit: 40943	16
MODEL C2® PLUS Shallow End Control Unit: 42012	16
MODEL C2® PLUS Proximity End Control: 40711	18
MODEL C2® PLUS SENSOR PLUS™ Standard End Cntl Unit: 42680	20
MODEL C2® PLUS SENSOR PLUS™ Shallow End Cntl Unit: 44880	20
MODEL H2™ End Control Unit, Single Phase: 24397	22
MODEL H2™ End Control Unit, Three Phase: 27762	22
MODEL H2™ PLUS End Control Unit: 40712	24
MODEL H2™ PLUS End Control Unit: 40815	24
MODEL H2™ PLUS SENSOR PLUS™ End Control: 45916	26
MODEL H2™ PLUS SENSOR PLUS™ End Control: 45917	26
MODEL G™ End Control Unit, Single Phase: 29511	28
MODEL G™ End Control Unit, Three Phase: 29521	28
MODEL G™ PLUS End Control Unit: 40944	30
MODEL G™ PLUS End Control Unit: 42028	30
MODEL G™ PLUS Proximity End Control: 40713	32
MODEL G™ PLUS SENSOR PLUS™ End Control: 42597	34
MODEL G™ PLUS SENSOR PLUS™ End Control: 44882	34
REVOLUTION® SENSOR PLUS™ End Control, 12 Spoke: 48047	36
REVOLUTION® SENSOR PLUS™ End Control, 8 Spoke: 48509	36
MODEL ATF™ End Control Unit: 6035	38
MODEL ATF™ End Control Unit: 49040	39
MODEL ATF™ SENSOR PLUS™ End Control Unit: 42643	40
MODEL ATF™ Drop Tube Assembly	41
MODEL ATF™ PLUS End Control Unit: 49146	42
MODEL ATF™ PLUS SENSOR PLUS™ End Control: 49148	43
MODEL ATF™ PLUS Drop Tube Assembly: 49147	44
Intermediate Control Units	46
MODEL C™ Intermediate Control Unit, Single Phase: 24190	46
MODEL C™ Intermediate Control Unit, Three Phase: 27758	46
MODEL C2® Intermediate Control Unit, Single Phase: 28117	48
MODEL C2® Intermediate Control Unit, Three Phase: 28275	48
MODEL C2® PLUS Intermediate Control Unit, Standard: 40945	50
MODEL C2® PLUS Intermediate Control Unit, Shallow: 42013	50
MODEL C2® Plus Proximity Intermediate Control: 40748	52
MODEL C2® PLUS Proximity Intermediate Control, Standard: 41020	53
MODEL C2® PLUS Proximity Intermediate Control, Shallow: 42016	53
MODEL C2® PLUS SENSOR PLUS™ Intermediate Control, Standard: 42663	54
MODEL C2® PLUS SENSOR PLUS™ Intermediate Control, Shallow: 44881	54
MODEL G™ Intermediate Control Unit, Single Phase: 29512	55
MODEL G™ Intermediate Control Unit, Three Phase: 29522	55
MODEL G™ PLUS Intermediate Control Unit, Standard: 40946	56

Contents - continued

Topic	Page
MODEL G™ PLUS Intermediate Control Unit, Shallow: 42029	56
MODEL G™ PLUS Proximity Intermediate Control: 40750	58
MODEL G™ PLUS SENSOR PLUS™ Intermediate Control, Standard: 42664	59
MODEL G™ PLUS SENSOR PLUS™ Intermediate Control, Shallow: 44883	59
MODEL H2™ Intermediate Control Unit, Single Phase: 25435	60
MODEL H2™ Intermediate Control Unit, Three Phase: 27760	60
MODEL H2™ PLUS Intermediate Control: 40745	62
MODEL H2™ PLUS Intermediate Control: 40817	62
MODEL H2™ PLUS SENSOR PLUS™ Intermediate Control: 45918	63
MODEL H2™ PLUS SENSOR PLUS™ Intermediate Control: 45919	63
REVOLUTION® SENSOR PLUS™ Mid-Line Control, 12 Spoke: 48048	64
REVOLUTION® SENSOR PLUS™ Mid-Line Control, 8 Spoke: 48510	64
Floor Feeder Power Units	65
Power Units	65
Power Unit Miscellaneous Components	66
ULTRAFLO® Drive Units	67
Boot Components	68
Single Broiler Boot Components: 6822	68
Single MODEL ATF™ Boot Components: 6821	68
Twin Broiler Boot Components: 6824	69
Twin MODEL ATF™ Boot Components: 8460	69
ULTRAPAN® Boot Assembly: 34824	70
ULRTAFLO® Boot: 35580	71
ULTRAFLO® Intake Cup Assembly (Domestic): 25167	72
ULTRAFLO® Intake Cup Assembly (International): 27380	72
Feed Hoppers	73
100# Hopper	73
150# Hopper: Part No. 48926	74
150# Hopper: Part No. 49267	74
150# Hopper: Part No. 49268	74
150# Hopper: Part No. 49269	74
200# Hopper: Part No. 9474	75
200# Hopper: Part No. 7941	75
300# Hopper	76
400# Hopper: Part No. 27530	77
Hopper Mount Bracket	78
Single Boot Hopper Support Kit: 34851	78
Twin Boot Hopper Support Kit: 38241	78
Hopper Mount Bracket	79
Hopper Suspension Kit: 49358	79
Feeder Line Components	80
Feeder Tubes	80
Broiler, Cockerel, & ATF™ Feeder Line Components	81
ULTRAPAN® Feeder Line Components	82
ULTRAFLO® Feeder Line Components	83
ULTRAFLO® Feeder Line Grill Options	84
ULTRAFLO® Clean-Out Assembly Kit: 35875	85
Pan Breeder Feeder Line Components	86
Indexing Gauge: 14251	86
MODEL ATF™ Feeder Line Winch Components	87
MODEL H2™ PLUS Feeder Line Winch Components	88

Contents - continued

Topic	Page
REVOLUTION® FEEDER Actuator System	89
Feeder Assemblies.	90
MODEL C™	90
Standard MODEL C™ Feeder	90
MODEL C™ Feeder (Slide Top)	90
MODEL C2®	91
2-Piece MODEL C2® Feeder	91
MODEL C2® Feeder (Slide Top)	91
1-Piece MODEL C2® Feeder	91
MODEL C2® PLUS	92
MODEL C2® PLUS Feeder	92
MODEL C2® PLUS Shallow Feeder	93
MODEL H	94
MODEL H2™	95
MODEL H2™ PLUS	96
MODEL H2™ PLUS Feeder w/Cords	96
MODEL H2™ PLUS Feeder w/o Cords	96
MODEL H2™ PLUS Removable Top Feeder w/Cords	96
MODEL H2™ PLUS Removeable Top Feeder w/o Cords	96
MODEL G™	97
2-Piece MODEL G™ Feeder	97
MODEL G™ Feeder (Slide Top)	97
1-Piece MODEL G™ Feeder	97
MODEL G™ PLUS	98
MODEL G™ PLUS Feeder	98
MODEL G™ PLUS Shallow Feeder	99
MODEL 2000™	100
REVOLUTION®	101
REVOLUTION® 12 Spoke Feeder Vari-Brood	101
REVOLUTION® 12 Spoke Feeder Non-Brood	101
REVOLUTION® 8 Spoke Feeder Vari-Brood	101
REVOLUTION® 8 Spoke Feeder Non-Brood	101
MODEL ATF™	102
MODEL ATF™ w/o Swing Down	102
MODEL ATF™ w/Swing Down	102
MODEL ATF™ PLUS	103
MODEL ATF™ PLUS w/o Swing Down	103
MODEL ATF™ PLUS w/Swing Down	103
MODEL ATF™ and ATF™ PLUS Optional Components	104
MODEL H2™ PLUS Pan Adapter	104
Suspension Components.	105
Miscellaneous Components	105
Power Winch: Part No 2883	106
Electric Power Lift: Part No 14580	107
Switch Box (for Electric Power Lift): Part No 14613	108
MULTI-LIFT® Winch Components	108
Limit Switch Assembly: 39464	109
Limit Switch Assembly: 29820-3	110
Electrical Controls and Components	111
Breeder Control Panel: Part No. 34380	111
Breeder Control Panel: Part No. 25175	112

Contents - continued

Topic	Page
Breeder Feeder Feed-Only Control Panel: Part No. 27440	113
MEAL-TIME™ Control Panel: Part No. 34385	114
Time Clock Control: Part No. 34574	115
Breeder Feeder Control: Part No. 8700A	116
MEAL-TIME™ Control Panel: Part No. 7022A	117
Time Clock Control 110 V: Part No. 27250	118
Time Clock Control 220 V: Part No. 26230	118
Time Clock Control 220 V: Part No. 26230	119
Tork Time Clocks	120
Contactor Control	120
Contactor Control: Part No 24545-1, 24545-2	121
Contactor Control: Part No 24392-1, 24392-2	121
Contactor Control: Part No 24392-1, 24392-2, 24392-3	122
Lower Hopper Switch: Part No 8798	123
Hopper Level Control: Part No. 2912	124
Hopper Level Control: Part No 14550	125
Hopper Level Control: Part No 27761 (International)	125
Winch Control: Part No. 34812	126
Floor Feeder Scale Systems and Components	127
Weigh Scale Template: Part No 5978	127
Weigh Scale Assembly	128
Beam Box Assembly: Part No. 5790	129
Model 100 & Model 200 Digital Indicators	130
Connection Box: Part No. 30266	130
J-Boxes & Cable Sets	131
J-Box Duplex Kit	131
Duplex J-Box	131
Miscellaneous Components and Cable Sets	131
Junction Control: Part No. 25784	132
Junction Control w/Fill Option: Part No. 30240	133
Junction Control w/Fill Option: 42550	134
Junction Control w/Fill Option: 42551	135
Dual Fill Control: 35021	136
Load Cells and Mount Kits	137
T.C. 15	137
T.C. 35 & 125	137
T.C. 180	137
C.T. 30K	138
6-Legged Bin Adapter Kit	138
Scale Systems available (by weight)	138
Power Supply	138
Livestock Scale Indicators	139
Livestock Scale Load Cells	139
Hopper Scales: Part No. 24176	140
Hopper Scales Switch Assembly: Part No. 33653	140
Scale Platform Assembly: 46280	141
Beam Bar Assembly: 46279	141
Switch Assembly: 46273	142
Floor Feeder Screener Components	143
WEIGH-MATIC® Model 90 Screener: 25432	143
WEIGH-MATIC® Model 90 Screener: 47730	144
WEIGH-MATIC® Model 90 Screener Control Unit	145

Contents - continued

Topic	Page
Junction Box Assembly: Part No. 25694	145
WEIGH-MATIC® Model 90 Screener Control Unit	146
Switch & Plate Assembly	147
Junction Box Assembly: 46071	148
WEIGH-MATIC® Model 90 Screener Power Units	149
Screener Power Unit 60 Hz.	149
Screener Power Unit 50 Hz.	149
Model 90 Bin Fill Cap Kit: Part No. 25806	150
Model 75 Bin Fill Cap Kit: Part No. 6563	150
Floor Feeder Miscellaneous Components.	151
Hens Only Grill (for Pan Breeder Feeder)	151
Program Gauge: Part No. 14251	151
Control Shield: Part No. 24887	151
Winchable Feed Level Tube Components	152

This Page Left Blank.